

AIR CONDITIONER

Wall mounted type

SERVICE MANUAL

INDOOR



ASUG09LZAS
ASUG12LZAS
ASUG15LZAS

OUTDOOR



AOUG09LZAH1
AOUG12LZAH1
AOUG15LZAH1

FUJITSU GENERAL LIMITED

Notices:

- Product specifications and design are subject to change without notice for future improvement.
- For further details, please check with our authorized dealer.

Trademarks

FGLair™ is trademark of Fujitsu General Limited in the United States, other countries or both.

Google Play™ is trademark of Google Inc.

App Store® is a service mark of Apple Inc., registered in the U.S. and other countries.

CONTENTS

1. GENERAL INFORMATION

2. TECHNICAL DATA AND PARTS LIST

3. TROUBLESHOOTING

4. CONTROL AND FUNCTIONS

5. FIELD WORKING

1. GENERAL INFORMATION

CONTENTS

1. GENERAL INFORMATION

1. Specifications.....01-1

1-1. Indoor unit01-1

1-2. Outdoor unit.....01-3

2. Dimensions.....01-4

2-1. Indoor unit01-4

2-2. Outdoor unit.....01-6

1. Specifications

1-1. Indoor unit

| Type | | | | Wall mounted | | | |
|-----------------------------|---------------------------------|-----------|--|--|--------------|----------------|-------------|
| | | | | Inverter heat pump | | | |
| Model name | | | | ASUG09LZAS | ASUG12LZAS | ASUG15LZAS | |
| Power supply | | | | 208/230 V ~ 60 Hz | | | |
| Power supply intake | | | | Outdoor unit | | | |
| Available voltage range | | | | 187—253 V | | | |
| Capacity | Cooling | Rated | kW | 2.64 | 3.52 | 4.25 | |
| | | | Btu/h | 9,000 | 12,000 | 14,500 | |
| | | Min.—Max. | kW | 0.91—3.52 | 0.91—3.99 | 0.91—5.39 | |
| | | | Btu/h | 3,100—12,000 | 3,100—13,600 | 3,100—18,400 | |
| | Heating | Rated | kW | 3.52 | 4.69 | 5.28 | |
| | | | Btu/h | 12,000 | 16,000 | 18,000 | |
| | | Min.—Max. | kW | 0.91—6.45 | 0.91—6.48 | 0.91—7.00 | |
| | | | Btu/h | 3,100—22,000 | 3,100—22,100 | 3,100—23,900 | |
| | Heating (17 °F) ¹ | Rated | kW | 2.17 | 2.93 | 3.28 | |
| | | | Btu/h | 7,400 | 10,000 | 11,200 | |
| | | Max. | kW | 4.69 | 5.13 | 6.30 | |
| | | | Btu/h | 16,000 | 17,500 | 21,500 | |
| Input power | Cooling | Rated | kW | 0.50 | 0.79 | 1.04 | |
| | | Min.—Max. | | 0.11—0.85 | 0.11—0.99 | 0.15—1.56 | |
| | Heating | Rated | | 0.66 | 1.01 | 1.15 | |
| | | Min.—Max. | | 0.17—1.93 | 0.17—1.94 | 0.15—2.19 | |
| | Heating (17 °F) ¹ | Rated | | 0.62 | 0.91 | 1.04 | |
| | | Max. | | 2.21 | 2.21 | 2.74 | |
| Current | Cooling | Rated | A | 2.5 | 3.8 | 4.8 | |
| | Heating | | 3.3 | 4.7 | 5.2 | | |
| EER | Cooling | | kW/kW | 5.28 | 4.46 | 4.09 | |
| | | | Btu/hW | 18.0 | 15.2 | 13.9 | |
| COP | Heating | | kW/kW | 5.33 | 4.64 | 4.59 | |
| | | | Btu/hW | 18.2 | 15.8 | 15.7 | |
| SEER | Cooling | | Btu/hW | 33.1 | 29.4 | 25.3 | |
| HSPF | Heating | | Btu/hW | 14.0 | 13.8 | 13.3 | |
| Power factor | Cooling | | % | 87 | 90 | 94 | |
| | Heating | | 87 | 93 | 96 | | |
| Moisture removal | | | pints/h (L/h) | 2.5 (1.2) | 2.7 (1.3) | 4.0 (1.9) | |
| Maximum operating current*2 | | Cooling | A | 9.4 | 9.4 | 9.9 | |
| | | Heating | | 11.9 | 11.9 | 14.4 | |
| Fan | Airflow rate | Cooling | HIGH | CFM (m³/h) | 542 (920) | 542 (920) | 583 (990) |
| | | | MED | | 406 (690) | 406 (690) | 459 (780) |
| | | | LOW | | 312 (530) | 312 (530) | 312 (530) |
| | | | QUIET | | 206 (350) | 206 (350) | 241 (410) |
| | | Heating | HIGH | | 542 (920) | 542 (920) | 600 (1,020) |
| | | | MED | | 406 (690) | 406 (690) | 459 (780) |
| | | | LOW | | 312 (530) | 312 (530) | 312 (530) |
| | | | QUIET | | 206 (350) | 206 (350) | 241 (410) |
| | Type × Q'ty | | | Crossflow fan × 1 | | | |
| | Motor output | | | W | | | |
| | Sound pressure level*3 | Cooling | HIGH | dB (A) | 43 | 43 | 45 |
| | | | MED | | 37 | 37 | 40 |
| LOW | | | 31 | | 31 | 32 | |
| QUIET | | | 23 | | 23 | 26 | |
| Heating | | HIGH | 43 | | 43 | 45 | |
| | | MED | 36 | | 36 | 39 | |
| | | LOW | 31 | | 31 | 32 | |
| | | QUIET | 23 | | 23 | 26 | |
| Heat exchanger type | Dimensions (H × W × D) | | in (mm) | Main1: 8-1/4 × 31-7/16 × 1-1/16 (210 × 798 × 26.6) Main2: 5-5/16 × 31-7/16 × 13/16 (135 × 798 × 20.0) Sub1: 3-5/16 × 31-7/16 × 1/2 (84 × 798 × 13.3) Sub2: 3-5/16 × 31-7/16 × 1/2 (84 × 798 × 13.3) | | | |
| | Fin pitch | | FPI | Main1: 21 Main2: 23 Sub1: 18 Sub2: 18 | | | |
| | Rows × Stages | | | Main1: 2 × 10 Main2: 2 × 8 Sub1: 1 × 4 Sub2: 1 × 4 | | | |
| | Pipe type | | | Copper | | | |
| | Fin type | | | Aluminum | | | |
| | Material | | | Polystyrene | | | |
| | Color | | | White | | | |
| Dimensions (H × W × D) | Net | in (mm) | Approximate color of Munsell N 9.25/ 11 × 38-9/16 × 9-7/16 (280 × 980 × 240) 12-11/16 × 42-7/16 × 13-5/8 (322 × 1,078 × 346) | | | | |
| Gross | | | | | | | |
| Weight | Net | lb (kg) | 29 (13) | | | | |
| | Gross | | 37 (17) | | | | |
| Connection pipe | Size | Liquid | in (mm) | Ø 1/4 (6.35) | | | |
| | | Gas | | Ø 3/8 (Ø 9.52) | | Ø 1/2 (Ø 12.7) | |
| Drain hose | Method | | | Flare | | | |
| | Material | | | PP+LLDPE | | | |
| Operation range | Tip diameter | | in (mm) | Ø17/32 (Ø 13.8) (I.D.), Ø5/8 to 21/32 (Ø 15.8 to 16.7) (O.D.) | | | |
| | Cooling | | °F (°C) | 64 to 90 (18 to 32) | | | |
| | | | %RH | 80 or less | | | |
| Remote controller type | Heating | | °F (°C) | 60 to 86 (16 to 30) | | | |
| | | | | Wireless (Wired, Mobile app*4 [FGLair™] [option]) | | | |

| Type | Wall mounted | | |
|--|--------------------|------------|------------|
| | Inverter heat pump | | |
| Model name | ASUG09LZAS | ASUG12LZAS | ASUG15LZAS |
| NOTES: <ul style="list-style-type: none"> Specifications are based on the following conditions: <ul style="list-style-type: none"> Cooling: Indoor temperature of 80 °FDB (26.67 °CDB) /67 °FWB (19.44 °CWB), and outdoor temperature of 95 °FDB (35 °CDB) / 75 °FWB (23.9 °CWB). Heating: Indoor temperature of 70 °FDB (21.11 °CDB) /59 °FWB (15.56 °CWB), and outdoor temperature of 47 °FDB (8.33 °CDB) /43 °FWB (6.11 °CWB). *1: Heating (17 °F): Indoor temperature of 70 °FDB (21.11 °CDB) /60 °FWB (15.56 °CWB), and outdoor temperature of 17 °FDB (-8.33 °CDB) /15 °FWB (-9.44 °CWB). Pipe length: 25 ft (7.5 m), Height difference: 0 ft (0 m). (Between outdoor unit and indoor unit.) Protective function might work when using it outside the operation range. *2: Maximum current is maximum value when operated within the operation range. *3: Sound pressure level: <ul style="list-style-type: none"> Measured values in manufacturer's anechoic chamber. Because of the surrounding sound environment, the sound levels measured in actual installation conditions might be higher than the specified values here. *4: Available on Google Play™ store or on App Store®. Optional WLAN adapter is also required. For details, refer to the setting manual. | | | |

1-2. Outdoor unit


| Type | | | | Inverter heat pump | | |
|---|------------------------|------------------------|-------------------|---|---------------|----------------|
| Model name | | | | AOUG09LZAH1 | AOUG12LZAH1 | AOUG15LZAH1 |
| Power supply | | | | 208/230 V ~ 60 Hz | | |
| Available voltage range | | | | 187—253 V | | |
| Starting current | | | | 3.3 | 4.7 | 5.2 |
| Fan | Airflow rate | Cooling | CFM (m³/h) | 1,089 (1,850) | 1,171 (1,990) | 1,218 (2,070) |
| | | Heating | | 1,089 (1,850) | 1,089 (1,850) | 1,348 (2,290) |
| | Type × Q'ty | | | Propeller fan × 1 | | |
| | Motor output | | W | 49 | | |
| Sound pressure level *1 | | Cooling | dB (A) | 46 | 47 | 49 |
| | | Heating | | 47 | 47 | 50 |
| Heat exchanger type | | Dimensions (H × W × D) | in (mm) | Main1: 23-1/8 × 34-11/16 × 11/16 (588 × 881 × 18.19) Main2: 23-1/8 ×33-1/2 × 11/16 (588 × 851 × 18.19) | | |
| | | Fin pitch | FPI | 20 | | |
| | | Rows × Stages | | Main1: 1 × 28 Main2: 1 × 28 | | |
| | | Pipe type | | Copper | | |
| | | Fin type | Type (Material) | Aluminum | | |
| | | | Surface treatment | PC fin | | |
| Compressor | Type | | | DC rotary | | |
| | Motor output | | W | 900 | 1,030 | |
| Refrigerant | Type | | | R410A | | |
| | | Charge | lb oz | 2 lb 14 oz | | 2 lb 16 oz |
| | | g | 1,300 | | 1,350 | |
| Refrigerant oil | | Type | RB68 | | | |
| | | Amount | in³ (cm³) | 24.4 (400) | | |
| Enclosure | | Material | | Steel sheet | | |
| | | Color | | Beige Approximate color of Munsell 10YR 7.5/1.0 | | |
| Dimensions (H × W × D) | Net | | in (mm) | 24-7/8 × 31-7/16 × 11-7/16 (632 × 799 × 290) | | |
| | Gross | | | 27-1/4 × 37 × 14-3/4 (692 × 940 × 375) | | |
| Weight | Net | | lb (kg) | 86 (39) | | 88 (40) |
| | Gross | | | 95 (43) | | |
| Connection pipe | Size | Liquid | in (mm) | Ø 1/4 (Ø 6.35) | | |
| | | Gas | | Ø 3/8 (Ø 9.52) | | Ø 1/2 (Ø 12.7) |
| | Method | | Flare | | | |
| | Pre-charge length | | ft (m) | 49 (15) | | |
| | Max. length | | | 66 (20) | | |
| | Max. height difference | | | 49 (15) | | |
| Operation range | | Cooling | °F (°C) | 14 to 115 (-10 to 46) | | |
| | | Heating | | -15 to 75 (-26 to 24) | | |
| NOTES: | | | | | | |
| <ul style="list-style-type: none">Specifications are based on the following conditions:<ul style="list-style-type: none">Cooling: Indoor temperature of 80 °FDB (26.67 °CDB) / 67 °FWB (19.44 °CWB), and outdoor temperature of 95 °FDB (35 °CDB) / 75 °FWB (23.9 °CWB).Heating: Indoor temperature of 70 °FDB (21.11 °CDB) / 59 °FWB (15 °CWB), and outdoor temperature of 47 °FDB (8.33 °CDB) / 43 °FWB (6.11 °CWB).Pipe length: 24 ft 6 in (7.5 m), Height difference: 0 ft (0 m). (Between outdoor unit and indoor unit.)Protective function might work when using it outside the operation range.*1: Sound pressure level<ul style="list-style-type: none">Measured values in manufacturer's anechoic chamber.Because of the surrounding sound environment, the sound levels measured in actual installation conditions might be higher than the specified values here. | | | | | | |

2. Dimensions

2-1. Indoor unit

■ Models: ASUG09LZAS, ASUG12LZAS, and ASUG15LZAS



Unit: in (mm)



● Installation space requirement

Provide sufficient installation space for product safety.


Unit: in (mm)




2-2. Outdoor unit

■ Models: AOUG09LZAH1, AOUG12LZAH1, and AOUG15LZAH1


Unit: in (mm)




Top view




Side view




Front view



Side view



Bottom view



Side view (Valve part)

2. TECHNICAL DATA AND PARTS LIST

CONTENTS

2. TECHNICAL DATA AND PARTS LIST

| | |
|--|--------------|
| 1. Precautions..... | 02-1 |
| 2. Indoor unit parts list..... | 02-2 |
| 2-1. Models: ASUG09LZAS, ASUG12LZAS, and ASUG15LZAS | 02-2 |
| 3. Outdoor unit parts list..... | 02-6 |
| 3-1. Models: AOUG09LZAH1, AOUG12LZAH1, and AOUG15LZAH1 | 02-6 |
| 4. Accessories | 02-10 |
| 4-1. Indoor unit | 02-10 |
| 4-2. Outdoor unit..... | 02-10 |
| 5. Optional parts | 02-11 |
| 5-1. Indoor unit | 02-11 |
| 6. Refrigerant system diagrams | 02-13 |
| 6-1. Models: AOUG09LZAH1, AOUG12LZAH1, and AOUG15LZAH1 | 02-13 |
| 7. Wiring diagrams | 02-14 |
| 7-1. Indoor unit | 02-14 |
| 7-2. Outdoor unit..... | 02-14 |
| 8. PC board diagrams | 02-15 |
| 8-1. Models: ASUG09LZAS, ASUG12LZAS, and ASUG15LZAS | 02-15 |
| 8-2. Models: AOUG09LZAH1, AOUG12LZAH1, and AOUG15LZAH1 | 02-16 |

1. Precautions

When you start servicing, pay attention to the following points. For detailed precautions, refer to the installation manual of the products.


CAUTION

-
- Service personnel
 - Any person who is involved with working on or breaking into a refrigerant circuit should hold a current valid certificate from an industry-accredited assessment authority, which authorizes their competence to handle refrigerants safely in accordance with an industry recognized assessment specification.
 - Servicing shall only be performed as recommended by the equipment manufacturer. Maintenance and repair requiring the assistance of other skilled personnel shall be carried out under the supervision of the person competent in the use of flammable refrigerants.
 - Servicing shall be performed only as recommended by the manufacturer.
 - Work
 - Work in confined spaces shall be avoided.
 - The area around the workspace shall be sectioned off.
 - Electric shock may occur. After turning off the power, always wait 5 minutes before touching electrical components.
 - Do not touch the fins of the heat exchanger. Touching the heat exchanger fins could result in damage to the fins or personal injury such as skin rupture.
 - Do not place any other electrical products or household belongings under the product.
 - Condensation dripping from the product might get them wet, and may cause damage or malfunction to the property.
-
- Service parts information and design are subject to change without notice for product improvement.
 - For the latest information of the service parts, refer to our Service Portal.
<https://fujitsu-general.force.com/portal/>
 - Precise figure of the service parts listed in this manual may differ from the actual service parts.

2. Indoor unit parts list


2-1. Models: ASUG09LZAS, ASUG12LZAS, and ASUG15LZAS

■ Exterior parts and Accessories



| Item no. | Part no. | Part name | Service part |
|----------|------------|--------------------------|--------------|
| 1 | 9323351004 | Bracket panel | ◆ |
| 2 | 9387476002 | Screw cap | ◆ |
| 3 | 9313951047 | Conduit holder | ◆ |
| 4 | 9387597035 | Wire cover assy | ◆ |
| 5 | 9383765032 | Wifi holder assy | ◆ |
| 6 | 9383634017 | Wireless LAN adapter | ◆ |
| 7 | 9387479010 | U/D louver assy | ◆ |
| 8 | 9332911008 | Electric filter holder | ◆ |
| 9 | 9323341005 | Under cover L | ◆ |
| 10 | 9317250009 | Air clean filter assy | ◆ |
| 11 | 9332438765 | Remote controller | ◆ |
| 12 | 9318912005 | Remote controller holder | ◆ |
| 13 | 9387596441 | Front panel total assy | ◆ |
| 14 | 9387756210 | Intake grille assy | ◆ |
| 15 | 9323340008 | Air filter | ◆ |
| 16 | 9333719009 | Grille clamper L | ◆ |
| 17 | 9333704005 | Grille clamper R | ◆ |
| 18 | 9323342002 | Under cover R | ◆ |
| 19 | 9383730023 | Louver spring | ◆ |
| 20 | 9333608006 | Bush | ◆ |
| <i>a</i> | — | Front panel | — |
| <i>b</i> | — | Panel cover | — |
| <i>c</i> | — | Front panel cover | — |
| <i>d</i> | — | Front panel B | — |

Chassis




| Item no. | Part no. | Part name | Service part |
|----------|------------|---|--------------|
| 50 | 9383735042 | Evaporator total assy (for 09-12 model) | ◆ |
| | 9383735059 | Evaporator total assy (for 15 model) | ◆ |
| 51 | 9387467000 | Room thermistor holder | ◆ |
| 52 | 9306489045 | Terminal | ◆ |
| 53 | 9711141392 | Main PCB (for 09 model) | ◆ |
| | 9711141408 | Main PCB (for 12 model) | ◆ |
| | 9711141415 | Main PCB (for 15 model) | ◆ |
| 54 | 9900627041 | Thermistor assy | ◆ |
| 55 | 9711146014 | Display assy | ◆ |
| 56 | 9317755061 | Pyroelectric sensor | ◆ |
| 57 | 9387589023 | Motor case assy | ◆ |
| 58 | 9603821005 | Brushless motor | ◆ |
| 59 | 9383565007 | Pipe bracket | ◆ |
| 60 | 9387488043 | Cable guide | ◆ |
| 61 | 9387714012 | Gear case assy | ◆ |
| 62 | 9383728006 | R and L louver SPM assy | ◆ |
| 63 | 9387590036 | Drain pan total assy | ◆ |
| 64 | 9316904002 | Drain hose assy | ◆ |
| 65 | 9316177017 | Drain cap | ◆ |
| 66 | 9387591019 | Drain pan assy | ◆ |
| 67 | 9383727009 | Spacer K assy | ◆ |
| 68 | 9333628004 | Bearing D assy | ◆ |
| 69 | 9387055054 | Crossflow fan assy | ◆ |
| 70 | 9387587029 | Base assy | ◆ |
| <i>a</i> | — | Control box | — |
| <i>b</i> | — | Control cover | — |
| <i>c</i> | — | Display case | — |
| <i>d</i> | — | Motor case | — |
| <i>e</i> | — | Motor cover assy | — |

3. Outdoor unit parts list

3-1. Models: AOUG09LZAH1, AOUG12LZAH1, and AOUG15LZAH1

■ Exterior parts and chassis




| Item no. | Part no. | Part name | Service part |
|----------|------------|--|--------------|
| 1 | 9322556028 | Top panel assy | ◆ |
| 2 | 9377854001 | Protective net assy | ◆ |
| 3 | 9322327000 | Thermistor holder | ◆ |
| 4 | 9322552242 | Cabinet right assy | ◆ |
| 5 | 9384276001 | Conduit cover | ◆ |
| 6 | 9322570062 | Switch cover assy | ◆ |
| 7 | 9901059025 | Heater base | ◆ |
| 8 | 9323540019 | Heater holder A | ◆ |
| 9 | 9323541016 | Heater holder B | ◆ |
| 10 | 9383720000 | Drain cap assy | ◆ |
| 11 | 9323550025 | Base assy | ◆ |
| 12 | 9322144003 | Drain pipe | ◆ |
| 13 | 9709684009 | Main PCB (for 09 model) | ◆ |
| | 9709684016 | Main PCB (for 12 model) | ◆ |
| | 9709684023 | Main PCB (for 15 model) | ◆ |
| 14 | 9900935054 | Thermistor assy | ◆ |
| 15 | 9900985011 | Thermistor assy (Compressor temp.) | ◆ |
| 16 | 9900565060 | Thermistor assy (Outdoor temp.) | ◆ |
| 17 | 9322420039 | Heat sink | ◆ |
| 18 | 9810028006 | Thermistor stopper | ◆ |
| 19 | 9317903011 | Emblem | ◆ |
| 20 | 9384273000 | Fan Guard | ◆ |
| 21 | 9322555182 | Front panel assy | ◆ |
| 22 | 9322150004 | Propeller fan | ◆ |
| 23 | 9603601003 | Brushless motor | ◆ |
| 24 | 9322553027 | Motor bracket assy | ◆ |
| 25 | 9317089616 | Condenser total assy (for 09-12 model) | ◆ |
| | 9317089654 | Condenser total assy (for 15 model) | ◆ |
| <i>a</i> | — | Inverter assy | — |
| <i>b</i> | — | Hair pin cushion | — |

■ Compressor

TECHNICAL DATA
AND PARTS LIST

TECHNICAL DATA
AND PARTS LIST



| Item no. | Part no. | Part name | Service part |
|----------|------------|------------------------------------|--------------|
| 50 | 9810542007 | Compressor (for 09-12 model) | ◆ |
| | 9810541000 | Compressor (for 15 model) | ◆ |
| 51 | 9322446015 | 4-way valve assy | ◆ |
| 52 | 9970194023 | Solenoid | ◆ |
| 53 | 9970173028 | Expansion valve coil | ◆ |
| 54 | 9322463029 | Pulse motor valve assy | ◆ |
| 55 | 9322474001 | 2-way valve assy | ◆ |
| 56 | 9322850010 | 3-way valve assy (for 09-12 model) | ◆ |
| | 9387831016 | 3-way valve assy (for 15 model) | ◆ |
| 57 | 9322824004 | S-insulator K | ◆ |
| 58 | 9323045002 | S-insulator V | ◆ |
| 59 | 9322501004 | S-insulator H | ◆ |
| 60 | 9322847003 | S-insulator F | ◆ |
| 61 | 9322503008 | S-insulator B | ◆ |
| <i>a</i> | — | Valve bracket | — |
| <i>b</i> | — | Muffler | — |



4. Accessories

4-1. Indoor unit

■ Models: ASUG09LZAS, ASUG12LZAS, and ASUG15LZAS

4-2. Outdoor unit





■ Models: AOUG09LZAH1, AOUG12LZAH1, and AOUG15LZAH1

| Part name | Exterior | Q'ty | Part name | Exterior | Q'ty |
|---------------------|---|------|-----------|---|------|
| Installation manual |  | 1 | Cable tie |  | 2 |

5. Optional parts

5-1. Indoor unit





■ Controllers

| Exterior | Part name | Model name | Summary |
|---|--------------------------|------------|---|
|  | Wired remote controller | UTY-RNRUZ* | <p>Easy finger touch operation with LCD panel. Backlit LCD enables easy operation in a dark room. Wire type: Non-polar 2-wire Optional communication kit is necessary for installation.</p> <p>NOTE: When this remote controller is connected, wireless remote controller cannot be used.</p>  |
|  | Simple remote controller | UTY-RSRY | <p>Compact remote controller concentrates on the basic functions such as Start/Stop, fan control, temperature setting, and operation mode. Wire type: Non-polar 2-wire Optional communication kit is necessary for installation.</p> |
|  | Simple remote controller | UTY-RHRY | <p>Compact remote controller concentrates on the basic functions such as Start/Stop, fan control, and temperature setting. Wire type: Non-polar 2-wire Optional communication kit is necessary for installation.</p> |

NOTES:


- Available functions may differ by the remote controller. For details, refer to the operation manual.
- When using a Wireless LAN adapter, group controlling system of the wired remote controller is prohibited.

Others

| Exterior | Part name | Model name | Summary |
|--|-------------------------------|------------|--|
|  | External connect kit | UTY-XWZXZ5 | Required when external device is connected. |
|  | External input and output PCB | UTY-XCSXZ2 | Use to connect with external devices and air conditioner PCB. Optional External connect kit is necessary for installation. |
|  | Communication kit | UTY-TWRXZ2 | Use to connect Non-polar 2-core wired remote controller. |
|  | Wireless LAN adapter | UTY-TFSXF3 | Remotely manage an air conditioning system using mobile devices such as smartphones and tablets. |

6. Refrigerant system diagrams

6-1. Models: AOUG09LZAH1, AOUG12LZAH1, and AOUG15LZAH1



Thc : Thermistor (Compressor temperature)

Thd : Thermistor (Discharge temperature)

Tho : Thermistor (Outdoor temperature)

Thho : Thermistor (Heat exchanger out temperature)

ThR : Thermistor (Room temperature)

ThPl : Thermistor (Pipe temperature)


7. Wiring diagrams

7-1. Indoor unit

■ Models: ASUG09LZAS, ASUG12LZAS, and ASUG15LZAS

7-2. Outdoor unit

■ Models: AOUG09LZAH1, AOUG12LZAH1, and AOUG15LZAH1




8-1. Models: ASUG09LZAS, ASUG12LZAS, and ASUG15LZAS



8-2. Models: AOUG09LZAH1, AOUG12LZAH1, and AOUG15LZAH1

INVERTER ASSEMBLY
AOUG09LZAS1 : EZ-0190MHUE
AOUG12LZAS1 : EZ-0190PHUE
AOUG15LZAS1 : EZ-0190THUE

AOUG09LZAH1 : EZ-0190RHUE
AOUG12LZAH1 : EZ-0190SHUE
AOUG15LZAH1 : EZ-0190WHUE



3. TROUBLESHOOTING

CONTENTS

3. TROUBLESHOOTING

| | |
|--|--------------|
| 1. Error code | 03-1 |
| 1-1. Error code table (Indoor unit and wired remote controller)..... | 03-1 |
| 1-2. Error code table (Wireless LAN indicator)..... | 03-2 |
| 1-3. Error code table (Mobile app) | 03-3 |
| 1-4. Error message for wireless LAN control (Mobile app)..... | 03-5 |
| 2. Troubleshooting with error code | 03-9 |
| 2-1. E: 11. Serial communication error (Serial reverse transfer error) (Outdoor unit)..... | 03-9 |
| 2-2. E: 11. Serial communication error (Serial forward transfer error) (Indoor unit) | 03-11 |
| 2-3. E: 12. Wired remote controller communication error (Indoor unit) | 03-13 |
| 2-4. E: 18. External communication error (Indoor unit) | 03-14 |
| 2-5. E: 32. Indoor unit main PCB error (Indoor unit) | 03-15 |
| 2-6. E: 35. MANUAL AUTO button error (Indoor unit)..... | 03-16 |
| 2-7. E: 41. Room temperature sensor error (Indoor unit) | 03-17 |
| 2-8. E: 42. Indoor unit heat exchanger sensor error (Indoor unit) | 03-18 |
| 2-9. E: 51. Indoor unit fan motor error (Indoor unit) | 03-19 |
| 2-10. E: 58. Intake grille error (Indoor unit) | 03-20 |
| 2-11. E: 62. Outdoor unit main PCB error (Outdoor unit) | 03-21 |
| 2-12. E: 63. Inverter error (Outdoor unit)..... | 03-22 |
| 2-13. E: 64. PFC circuit error (Outdoor unit) | 03-23 |
| 2-14. E: 71. Discharge thermistor error (Outdoor unit)..... | 03-24 |
| 2-15. E: 73. Outdoor unit heat exchanger thermistor error (Outdoor unit)..... | 03-25 |
| 2-16. E: 74. Outdoor temperature thermistor error (Outdoor unit)..... | 03-26 |
| 2-17. E: 84. Current sensor error (Outdoor unit) | 03-27 |
| 2-18. E: 94. Trip detection (Outdoor unit)..... | 03-28 |
| 2-19. E: 95. Compressor motor control error (Outdoor unit) | 03-29 |
| 2-20. E: 97. Outdoor unit fan motor error (Outdoor unit) | 03-30 |
| 2-21. E: 99. 4-way valve error (Outdoor unit)..... | 03-32 |
| 2-22. E: A1. Discharge temperature error (Outdoor unit) | 03-34 |
| 3. Troubleshooting without error code..... | 03-36 |
| 3-1. Indoor unit—No power | 03-36 |
| 3-2. Outdoor unit—No power | 03-37 |
| 3-3. No operation (Power is on) | 03-38 |
| 3-4. No cooling/No heating | 03-39 |
| 3-5. Abnormal noise..... | 03-41 |
| 3-6. Water leaking..... | 03-42 |
| 3-7. Too warm | 03-43 |
| 3-8. Too cool..... | 03-47 |
| 4. Troubleshooting with error code (For wireless LAN adapter)..... | 03-51 |
| 4-1. E: 18. External communication error between indoor unit and WLAN adapter | 03-51 |
| 4-2. Wireless LAN adapter error | 03-52 |
| 4-3. Network communication error between wireless LAN router and WLAN adapter | 03-53 |

CONTENTS (continued)

| | |
|--|--------------|
| 4-4. E: 18. Communication error..... | 03-55 |
| 4-5. E: 18. Wireless LAN adapter non-energized..... | 03-57 |
| 4-6. Wireless LAN adapter Sleep mode (Indoor unit) | 03-58 |
| 4-7. Mobile app setting method..... | 03-59 |
| 5. Service parts information | 03-64 |
| 5-1. Compressor | 03-64 |
| 5-2. Inverter compressor..... | 03-65 |
| 5-3. Outdoor unit Electronic Expansion Valve (EEV) | 03-66 |
| 5-4. Indoor unit fan motor | 03-68 |
| 5-5. Outdoor unit fan motor..... | 03-69 |
| 6. Thermistor resistance values..... | 03-70 |
| 6-1. Indoor unit | 03-70 |
| 6-2. Outdoor unit..... | 03-71 |

1. Error code

1-1. Error code table (Indoor unit and wired remote controller)


The operation, timer, and economy indicators operate according to the error contents.

For confirmation of the error contents, refer the flashing pattern as follows.


| Error contents | Indoor unit display | | | Wired remote controller display |
|--|-----------------------|--------------------|---------------------|---------------------------------|
| | Operation [I] (Green) | Timer [⏰] (Orange) | Economy [E] (Green) | |
| E: 11. Serial communication error (Serial reverse transfer error) (Outdoor unit) | 1 times | 1 times | Continuous | 11 |
| E: 11. Serial communication error (Serial forward transfer error) (Indoor unit) | 1 times | 1 times | Continuous | 11 |
| E: 12. Wired remote controller communication error (Indoor unit) | 1 times | 2 times | Continuous | 12 |
| E: 18. External communication error (Indoor unit) | 1 times | 8 times | Continuous | 18 |
| E: 18. External communication error between indoor unit and WLAN adapter | 1 times | 8 times | Continuous | 18 |
| E: 18. Communication error | 1 times | 8 times | Continuous | 18 |
| E: 18. Wireless LAN adapter non-energized | 1 times | 8 times | Continuous | 18 |
| E: 32. Indoor unit main PCB error (Indoor unit) | 3 times | 2 times | Continuous | 32 |
| E: 35. MANUAL AUTO button error (Indoor unit) | 3 times | 5 times | Continuous | 35 |
| E: 41. Room temperature sensor error (Indoor unit) | 4 times | 1 times | Continuous | 41 |
| E: 42. Indoor unit heat exchanger sensor error (Indoor unit) | 4 times | 2 times | Continuous | 42 |
| E: 51. Indoor unit fan motor error (Indoor unit) | 5 times | 1 times | Continuous | 51 |
| E: 58. Intake grille error (Indoor unit) | 5 times | 8 times | Continuous | 58 |
| E: 62. Outdoor unit main PCB error (Outdoor unit) | 6 times | 2 times | Continuous | 62 |
| E: 63. Inverter error (Outdoor unit) | 6 times | 3 times | Continuous | 63 |
| E: 64. PFC circuit error (Outdoor unit) | 6 times | 4 times | Continuous | 64 |
| E: 71. Discharge thermistor error (Outdoor unit) | 7 times | 1 times | Continuous | 71 |
| E: 73. Outdoor unit heat exchanger thermistor error (Outdoor unit) | 7 times | 3 times | Continuous | 73 |
| E: 74. Outdoor temperature thermistor error (Outdoor unit) | 7 times | 4 times | Continuous | 74 |
| E: 84. Current sensor error (Outdoor unit) | 8 times | 4 times | Continuous | 84 |
| E: 94. Trip detection (Outdoor unit) | 9 times | 4 times | Continuous | 94 |
| E: 95. Compressor motor control error (Outdoor unit) | 9 times | 5 times | Continuous | 95 |
| E: 97. Outdoor unit fan motor error (Outdoor unit) | 9 times | 7 times | Continuous | 97 |
| E: 99. 4-way valve error (Outdoor unit) | 9 times | 9 times | Continuous | 99 |
| E: A1. Discharge temperature error (Outdoor unit) | 10 times | 1 times | Continuous | A1 |

1-2. Error code table (Wireless LAN indicator)

- Wireless LAN control system diagram example



- Name of parts



- Wireless LAN indicator

For confirmation of the error contents, refer the flashing pattern as follows.


Wireless LAN LED (orange) on the indoor unit operate according to the error contents.


| Error contents | Wireless LAN LED (orange) | Error code |
|--|---|------------|
| E: 18. External communication error between indoor unit and WLAN adapter | On: Connection information with router is available Off: Connection information with router is unavailable | 18 |
| Wireless LAN adapter error | Flashing slow | No error |
| Network communication error between wireless LAN router and WLAN adapter | On | No error |
| E: 18. Communication error | Flashing slow | 18 |
| E: 18. Wireless LAN adapter non-energized | Off | 18 |
| Wireless LAN adapter Sleep mode (Indoor unit) | Off | No error |

Flashing slow: Repeating 7 seconds on/2 seconds off


1-3. Error code table (Mobile app)

- Error display

If there is an abnormality on the air conditioning, refer to  as follows.

When the  (error button) on the home screen is tapped, error code and error name is displayed.

– For Android



– For iOS



- Error code

| Error message | Error contents | Error code |
|---|--|------------|
| Serial communication error (Serial Reverse Transfer Error) | E: 11. Serial communication error (Serial reverse transfer error) (Outdoor unit) | 11.1 |
| | | 11.2 |
| Serial communication error (Serial Forward Transfer Error) | E: 11. Serial communication error (Serial forward transfer error) (Indoor unit) | 11.3 |
| | | 11.4 |
| Wired remote controller communication error | E: 12. Wired remote controller communication error (Indoor unit) | 12.1 |
| Indoor unit PCB model information error | E: 32. Indoor unit main PCB error (Indoor unit) | 32.1 |
| Manual auto switch error | E: 35. MANUAL AUTO button error (Indoor unit) | 35.1 |
| Room temp. sensor error | E: 41. Room temperature sensor error (Indoor unit) | 41.1 |
| Indoor unit Heat Ex. Middle temp. sensor error | E: 42. Indoor unit heat exchanger sensor error (Indoor unit) | 42.2 |
| Indoor unit fan motor error | E: 51. Indoor unit fan motor error (Indoor unit) | 51.1 |
| | | 51.2 |
| Outdoor unit main PCB model information error | E: 62. Outdoor unit main PCB error (Outdoor unit) | 62.1 |
| | | 62.2 |
| Inverter error | E: 63. Inverter error (Outdoor unit) | 63.1 |
| | | 63.2 |
| PC circuit error | E: 64. PFC circuit error (Outdoor unit) | 64.1 |
| | | 64.3 |
| | | 64.4 |
| | | 64.8 |
| Discharge temp. sensor error | E: 71. Discharge thermistor error (Outdoor unit) | 71.1 |
| Outdoor unit Heat Ex. liquid temp. sensor error | E: 73. Outdoor unit heat exchanger thermistor error (Outdoor unit) | 73.3 |
| Outdoor temp. sensor error | E: 74. Outdoor temperature thermistor error (Outdoor unit) | 74.1 |
| Current sensor error | E: 84. Current sensor error (Outdoor unit) | 84.1 |
| Trip detection | E: 94. Trip detection (Outdoor unit) | 94.1 |
| Compressor rotor position detection error | E: 95. Compressor motor control error (Outdoor unit) | 95.1 |
| | | 95.3 |
| Outdoor unit fan motor error | E: 97. Outdoor unit fan motor error (Outdoor unit) | 97.3 |
| 4-way valve error | E: 99. 4-way valve error (Outdoor unit) | 99.1 |
| Discharge temp. error | E: A1. Discharge temperature error (Outdoor unit) | A1.1 |


1-4. Error message for wireless LAN control (Mobile app)

- Error display


If there is an abnormality on the wireless control system, refer to error messages as follows.

The error message disappears after 5 seconds and the normal screen is displayed.

For Android



For iOS



- Error message list
 - For Android

| Registration error | | |
|--|---|--|
| Error message | Cause | Solution |
| Wi-Fi must be enabled to set up new device | The user has disabled Wi-Fi on the smart device. | Enable the Wi-Fi on the smart device. |
| We weren't able to sign you onto null. Please goto the Wi-Fi settings and join the network from there. Return to the app when you're done. | The smart device and air conditioner are connected to difference Wi-Fi networks when attempting to register. | Connect the mobile device to the same network as air conditioner, then retry the registration. |
| Could not connect to the device at this time. Please reset the device and try again. | The air conditioner is not connected to Wi-Fi. | Check if the router connected to the air conditioner has internet access. (You can check by connecting the smart device to the router, then opening the website.) If there is no access, connect the router to the internet. |
| | Smart device is not connected to the same network as the air conditioner. | Connect the mobile device to the same network as the air conditioner, then retry the registration. |
| The device failed to connect with service. | Your internet access may be down or a firewall may be blocking requests to the service. | Check if the router connected to the air conditioner has internet access. (You can check by connecting the smart device to the router, then opening the website.) If there is no access, connect the router to the internet. |
| Could not register the device. Make sure the device is ready for registration. | The air conditioner is not connected to the router. | Enter the Wi-Fi setting on the smart device, then check if the SSID of the air conditioner (AP-WF*-*****-*) is connected. If the air conditioner is connected, retry the registration. |
| | The router the air conditioner is connected to, has no internet access. | Check if the router connected to the air conditioner has internet access. (You can check by connecting the smart device to the router, then opening the website.) If there is no access, connect the router to the internet. |
| | The air conditioner is already registered. | If there is a smart device that has already been registered to the air conditioner, unregister by using the registered smart device. Retry the registration with the smart device you wish to register. If you do not own the smart device registered to the air conditioner (lost, property of previous owner, etc.), ask your maker service to unregister the smart device. Notify the MAC address of the WLAN adapter as written on the Wireless LAN label. |
| | If the problem persists even if the all of the above is conducted, please contact your dealer or authorized service personnel. When asking for advice, Notify the MAC address of the WLAN adapter as written on the Wireless LAN label. | |
| Please ensure your air conditioner is ready to pair, and that you have entered its SSID and password correctly. | Occurs when pairing is executed, when the user erroneously enter the SSID of the adapter. | Enter the SSID literally. (Uppercase and lowercase letters also match) |

| General error | | |
|--|---|---|
| Error message | Cause | Solution |
| No connectivity to Wi-Fi or the cloud. Please check your network connection. | The smart device has no internet access. | Connect the mobile device to the internet. |
| An error occurred while trying to update your profile. Please try again later. | | |
| Device is offline and cannot be modified. | The router the air conditioner is connected to, has no internet access. | Check if the router connected to the air conditioner has internet access. (You can check by connecting the mobile device to the router, then opening the website.) If there is no access, connect the router to the internet. |
| | The air conditioner is not connected to the router. | Check the W-LAN LED indicators on the air conditioner. If the W-LAN LED lamp is flashing or off, refer to "Error code table (Wireless LAN indicator)" on page 03-2 |

| Sign in error | | |
|--------------------------|--|---|
| Error message | Cause | Solution |
| Could not reach service. | The smart device has no internet access. | Connect the smart device to the internet. |

– For iOS

| Registration error | | |
|--|---|--|
| Error message | Cause | Solution |
| You need an internet connection to add new devices. | The user has disabled Wi-Fi on their smart device. | Enable Wi-Fi from the iOS setting. |
| Could not register same LAN device. Make sure both devices are in the same LAN and try again to register. | The smart device and air conditioner are connected to different Wi-Fi networks when attempting to register. | Connect the smart device to the same network as the air conditioner, then retry the registration. |
| No registrable device was found. Make sure Wi-Fi setup was successful. This method only works if the Wi-Fi was recently performed. | The air conditioner is not connected to Wi-Fi. | Check if the router connected to the air conditioner has internet access. (You can check by connecting the smart device to the router, then opening the website.) If there is no access, connect the router to the internet. |
| | Smart device is not connected to the same network as the air conditioner. | Connect the mobile device to the same network as the air conditioner, then tap register button. |
| Could not register the device. Make sure the device is ready for registration. | The air conditioner is not connected to the router. | Enter the Wi-Fi setting on the smart device, then check if the SSID of the air conditioner (AP-WF**-*****-*) is connected. If the air conditioner is connected, retry the registration. |

| Registration error | | |
|---|--|--|
| Error message | Cause | Solution |
| Could not register the device. Make sure the device is ready for registration. | The router the air conditioner is connected to, has no internet access. | Check if the router connected to the air conditioner has internet access. (You can check by connecting the smart device to the router, then opening the website.) If there is no access, connect the router to the internet, then retry the registration. |
| | The air conditioner is already registered. | If there is a smart device that has already been registered to the air conditioner, unregister by using the registered smart device. Retry the registration with the smart device you wish to register. If you do not own the smart device registered to the air conditioner (lost, property of previous owner, etc.), ask your maker service to unregister the smart device. Notify the MAC address of the WLAN adapter as written on the Wireless LAN label. |
| | If the problem persists even if the all of the above is conducted, please contact your dealer or authorized service personnel. When asking for advice, please notify the MAC address of the WLAN adapter as written on the Wireless LAN label. | |
| Please ensure your air conditioner is ready to pair, and that you have entered its SSID and password correctly. | Occurs when pairing is executed, when the user erroneously enter the SSID of the adapter. | Enter the SSID literally. (Uppercase and lowercase letters also match) |

| General error | | |
|---|--|---|
| Error message | Cause | Solution |
| Failed to change password. Cloud not determine service reachability. Failed to update property. Could not retrieve schedules. The operation couldn't be completed. Operation timed out. | The smart device has no internet access. | Connect the mobile device to the internet. |
| "Device name" is offline. (Device name varies depending on the air conditioner) | The router the air conditioner is connected to has no internet access. | Check if the router connected to the air conditioner has internet access. (You can check by connecting the mobile device to the router, then opening the website to check access.) If there is no access, connect the router to the internet. |
| | The air conditioner is not connected to the router. | Check the W-LAN LED indicators on the air conditioner. If the W-LAN LED lamp is flashing or off, refer to " Error code table (Wireless LAN indicator) " on page 03-2 |

| Sign in error | | |
|--------------------------|--|---|
| Error message | Cause | Solution |
| Could not reach service. | The smart device has no internet access. | Connect the smart device to the internet. |

2. Troubleshooting with error code

2-1. E: 11. Serial communication error (Serial reverse transfer error) (Outdoor unit)

| | | | |
|--------------------|--------------|---------------------|---|
| Indicator | Indoor unit | Operation indicator | 1 time flash |
| | | Timer indicator | 1 time flash |
| | | Economy indicator | Continuous flash |
| | | Error code | E: 11 |
| Detective actuator | Outdoor unit | Main PCB | When the indoor unit cannot receive the serial signal from outdoor unit more than 2 minutes after power on, or the indoor unit cannot receive the serial signal more than 15 seconds during normal operation. |
| | | Fan motor | |
| Forecast of cause | | | Connection failure |
| | | | External cause |
| | | | Main PCB failure |
| | | | Outdoor unit fan motor failure |

Check point 1. Reset the power and operate

Does error indication show again?

→ If no, go to "Check point 1-2".



Check point 2. Check connection

Check any loose or removed connection line of indoor unit and outdoor unit.

Check connection condition is control unit. (If there is loose connector, open cable or mis-wiring.)

→ If there is an abnormal condition, correct it by referring to the installation manual or the "DESIGN & TECHNICAL MANUAL".



Check point 3. Check the voltage of power supply


Check the voltage of power supply

Check if AC 187 V (AC 208 V -10%) to AC 253 V (AC 230 V +10%) appears at outdoor unit terminal L—N.



Check point 4. Check serial signal (Reverse transfer signal)

Check serial signal (Reverse transfer signal)



- Check if indicated value swings between AC 90 V and AC 270 V at the outdoor unit terminal 1 —3.
- If it is abnormal, check the parts below.
 - Outdoor unit fan motor in "[Service parts information](#)" on page 03-64
- If outdoor fan motor is abnormal, replace outdoor unit fan motor and main PCB.
- If the checked parts are normal, replace the main PCB.



End

Check point 1-2. Check external cause such as noise

- Check the complete insulation of the grounding.
- Check if there is any equipment that causes harmonic wave near the power cable (Neon light bulb or any electronic equipment which causes harmonic wave).



End

2-2. E: 11. Serial communication error (Serial forward transfer error) (Indoor unit)

| | | | |
|--------------------|-------------|---------------------|---|
| Indicator | Indoor unit | Operation indicator | 1 time flash |
| | | Timer indicator | 1 time flash |
| | | Economy indicator | Continuous flash |
| | | Error code | E: 11 |
| Detective actuator | Indoor unit | Main PCB | When the outdoor unit cannot receive the serial signal from indoor unit more than 10 seconds. |
| | | Fan motor | |
| Forecast of cause | | | Connection failure |
| | | | External cause |
| | | | Main PCB failure |
| | | | Indoor unit fan motor failure |

Check point 1. Reset the power and operate

Does error indication show again?

→ If no, go to "Check point 1-2".



Check point 2. Check connection

Check any loose or removed connection line of indoor unit and outdoor unit.

Check connection condition is control unit. (If there is loose connector, open cable or mis-wiring.)

→ If there is an abnormal condition, correct it by referring to the installation manual or the "DESIGN & TECHNICAL MANUAL".



Check point 3. Check the voltage of power supply


Check the voltage of power supply

Check if AC 187 V (AC 208 V -10%) to AC 253 V (AC 230 V +10%) appears at outdoor unit terminal L—N.



Check point 4. Check serial signal (reverse transfer signal)

Check serial signal (Forward transfer signal)



- Check if indicated value swings between AC 30 V and AC 130 V at outdoor unit terminal 2—3.
- If it is abnormal, replace main PCB.
- If it is abnormal, check indoor unit fan motor. (Indoor unit fan motor in ["Service parts information"](#) on page 03-64)
- If indoor unit fan motor is abnormal, replace indoor unit fan motor and main PCB.



End

Check point 1-2. Check external cause such as noise

- Check the complete insulation of the grounding.
- Check if there is any equipment that causes harmonic wave near the power cable (Neon light bulb or any electronic equipment which causes harmonic wave).



End

2-3. E: 12. Wired remote controller communication error (Indoor unit)

| | | | |
|--------------------|----------------------|---------------------|---|
| Indicator | Indoor unit | Operation indicator | 1 time flash |
| | | Timer indicator | 2 time flash |
| | | Economy indicator | Continuous flash |
| | | Error code | E: 12 |
| Detective actuator | Indoor unit | Main PCB | When the indoor unit cannot receive the signal from Wired remote controller more than 1 minute during normal operation. |
| | Wired remote control | | |
| Forecast of cause | | | Terminal connection abnormal |
| | | | Wired remote control failure |
| | | | Main PCB failure |

Check point 1. Check the connection of terminal

After turning off the power, check & correct the followings.

- Check the connection of terminal between remote controller and indoor unit, and check if there is a disconnection of the cable.



Check point 2. Check connection

Check voltage at CN2 (terminal 1—3) of UTY-TWRXZ2 (Communication kit). (Power supply to the remote controller)
Upon correcting the removed connector or mis-wiring, reset the power.



- If it is DC 5 V, remote controller is failure. (Main PCB is normal)
 - Replace Remote Control
- If it is DC 0 V, main PCB is failure. (Check remote controller once again)
 - Replace main PCB



End

2-4. E: 18. External communication error (Indoor unit)

| | | | |
|--------------------|-------------|------------------------------|--|
| Indicator | Indoor unit | Operation indicator | 1 time flash |
| | | Timer indicator | 8 time flash |
| | | Economy indicator | Continuous flash |
| | | Error code | E: 18 |
| Detective actuator | Indoor unit | External communication error | After receiving a signal from the external input and output PCB, the same signal has not been received for 15 seconds. |
| Forecast of cause | | | Connection failure |
| | | | External input and output PCB failure |
| | | | Main PCB |

Check point 1. Check the connection

- Check any loose or removed connection between the main PCB to the external input and output PCB.
-> If there is an abnormal condition, correct it by refer to the installation manual or the "DESIGN & TECHNICAL MANUAL".
- Check the connection condition on the external input and output PCB and the main PCB (If there is loose connector, open cable or mis-wiring.)



Check point 2. Replace the external input and output PCB

If check point 1 do not improve the symptom, change external input and output PCB



Check point 3. Replace main PCB

If check point 2 do not improve the symptom, change main PCB



End

2-5. E: 32. Indoor unit main PCB error (Indoor unit)

| | | | |
|--------------------|-------------|---------------------|---|
| Indicator | Indoor unit | Operation indicator | 3 time flash |
| | | Timer indicator | 2 time flash |
| | | Economy indicator | Continuous flash |
| | | Error code | E: 32 |
| Detective actuator | Indoor unit | main PCB | When power is on and there is some below case. 1. When model information of EEPROM is incorrect. 2. When the access to EEPROM failed. |
| Forecast of cause | | | External cause |
| | | | Defective connection of electric components |
| | | | Main PCB failure |

Check point 1. Reset power supply and operate

Does error indication show again?

→ If no, go to "Check point 1-2".



Check point 2. Check Indoor unit electric components

- Check all connectors. (loose connector or incorrect wiring)
- Check any shortage or corrosion on PCB.



Check point 3. Replace main PCB

Change main PCB.



End

Check point 1-2. Check external cause such as noise

- Check if the ground connection is proper.
- Check if there is any equipment that causes harmonic wave near the power cable (Neon light bulb or any electronic equipment which causes harmonic wave).



End

NOTE: EEPROM

EEPROM (Electrically Erasable and Programmable Read Only Memory) is a non-volatile memory which keeps memorized information even if the power is turned off. It can change the contents electronically. To change the contents, it uses higher voltage than normal, and it cannot change a partial contents. (Rewriting shall be done upon erasing the all contents.) There is a limit in a number of rewriting.

2-6. E: 35. MANUAL AUTO button error (Indoor unit)

| | | | |
|--------------------|----------------------------|---------------------|--|
| Indicator | Indoor unit | Operation indicator | 3 time flash |
| | | Timer indicator | 5 time flash |
| | | Economy indicator | Continuous flash |
| | | Error code | E: 35 |
| Detective actuator | Indoor unit controller PCB | | When the MANUAL AUTO button becomes on for consecutive 30 or more seconds. |
| | Indicator PCB | | |
| | Manual auto switch | | |
| Forecast of cause | | | MANUAL AUTO button failure |
| | | | Controller PCB and indicator PCB failure |

Check point 1. Check the MANUAL AUTO button

- Check if MANUAL AUTO button is kept pressed.
- Check On/Off switching operation by using a meter.



If MANUAL AUTO button is disabled (on/off switching), replace it.



Check point 2. Replace main PCB and indicator PCB

If Check Point 1 does not improve the symptom, change main PCB and indicator PCB.



End

2-7. E: 41. Room temperature sensor error (Indoor unit)

| | | | |
|--------------------|-----------------------------|--|------------------|
| Indicator | Indoor unit | Operation indicator | 4 time flash |
| | | Timer indicator | 1 time flash |
| | | Economy indicator | Continuous flash |
| | | Error code | E: 41 |
| Detective actuator | Indoor unit main PCB | Room temperature thermistor is open or short is detected always. | |
| | Room temperature thermistor | | |
| Forecast of cause | | Connector failure | |
| | | Thermistor failure | |
| | | Main PCB failure | |

Check point 1. Check connection of connector


- Check if connector is loose or removed.
- Check erroneous connection.
- Check if thermistor cable is open

-> Reset power when reinstalling due to removed connector or incorrect wiring.



Check point 2. Remove connector and check thermistor resistance value

- For the room thermistor resistance value, refer to "[Thermistor resistance values](#)" on page 03-70.
- If thermistor is either open or shorted, replace it and reset the power.



Check point 3. Check voltage of main PCB

Make sure circuit diagram of each indoor unit and check terminal voltage at thermistor (DC 5.0 V).

NOTE: For details of thermistor connector, refer to "[Wiring diagrams](#)" in Chapter 2. TECHNICAL DATA AND PARTS LIST on page 02-14.
If the voltage does not appear, replace main PCB.



End

2-8. E: 42. Indoor unit heat exchanger sensor error (Indoor unit)

| | | | |
|--------------------|---------------------------------------|---|------------------|
| Indicator | Indoor unit | Operation indicator | 4 time flash |
| | | Timer indicator | 2 time flash |
| | | Economy indicator | Continuous flash |
| | | Error code | E: 42 |
| Detective actuator | Indoor unit main PCB | When heat exchanger temperature thermistor open or short circuit is detected. | |
| | Heat exchanger temperature thermistor | | |
| Forecast of cause | | Connector connection failure | |
| | | Thermistor failure | |
| | | Main PCB failure | |

Check point 1. Check connection of connector


- Check if connector is loose or removed.
- Check erroneous connection.
- Check if thermistor cable is open

-> Reset power when reinstalling due to removed connector or incorrect wiring.



Check point 2. Remove connector and check thermistor resistance value

- For the room thermistor resistance value, refer to "[Thermistor resistance values](#)" on page 03-70.
- If thermistor is either open or shorted, replace it and reset the power.



Check point 3. Check voltage of main PCB

Make sure circuit diagram of each indoor unit and check terminal voltage at thermistor (DC 5.0 V).

NOTE: For details of thermistor connector, refer to "[Wiring diagrams](#)" in Chapter 2. TECHNICAL DATA AND PARTS LIST on page 02-14.
If the voltage does not appear, replace main PCB.



End

2-9. E: 51. Indoor unit fan motor error (Indoor unit)

| | | | |
|--------------------|-------------|---------------------|--|
| Indicator | Indoor unit | Operation indicator | 5 time flash |
| | | Timer indicator | 1 time flash |
| | | Economy indicator | Continuous flash |
| | | Error code | E: 51 |
| Detective actuator | Indoor unit | main PCB | When the condition that actual frequency of indoor fan is below 1/3 of target frequency is continued more than 56 seconds. |
| | | Fan motor | |
| Forecast of cause | | | Fan rotation failure |
| | | | Fan motor winding open |
| | | | Motor protection by surrounding temperature rise |
| | | | Control PCB failure |
| | | | Indoor unit fan motor failure |

Check point 1. Check rotation of fan

Rotate the fan by hand when operation is off. (Check if fan is caught, dropped off or locked motor)
→ If fan or bearing is abnormal, replace it.



Check point 2. Check ambient temp. around motor

Check excessively high temperature around the motor. (If there is any surrounding equipment that causes heat)
→ Upon the temperature coming down, restart operation.



Check point 3. Check indoor unit fan motor

Check Indoor unit fan motor. (Refer to indoor unit fan motor in ["Service parts information"](#) on page 03-64.)
→ If Indoor unit fan motor is abnormal, replace Indoor unit fan motor.



Check point 4. Replace main PCB

If Check Point 1 to 3 do not improve the symptom, replace main PCB.



End


2-10. E: 58. Intake grille error (Indoor unit)

| | | | |
|--------------------|----------------------|--|------------------------|
| Indicator | Indoor unit | Operation indicator | 5 time flash |
| | | Timer indicator | 8 time flash |
| | | Economy indicator | Continuous flash |
| | | Error code | E: 58 |
| Detective actuator | Indoor unit main PCB | When the Micro switch is detected open while running the compressor. | |
| | Micro switch | | |
| Forecast of cause | | | Micro switch failure |
| | | | Shorted connector/wire |
| | | | Main PCB failure |

Check point 1. Check limit switch

- Check operation of Micro switch. (any blocking by dust, etc.)
- Remove Micro switch and check ON/OFF switching operation by using a meter.

-> If micro switch is detective, replace it.



Check point 2. Check Connector (CN11)/wire

Check loose contact of CN11/shorted wire (pinched wire).

-> Replace micro switch if the wire is abnormal



Check point 3. Replace main PCB

If Check Point 1 and 2 do not improve the symptom, change main PCB.



End

2-11. E: 62. Outdoor unit main PCB error (Outdoor unit)

| | | | |
|--------------------|--------------|---------------------|---|
| Indicator | Indoor unit | Operation indicator | 6 time flash |
| | | Timer indicator | 2 time flash |
| | | Economy indicator | Continuous flash |
| | | Error code | E: 62 |
| Detective actuator | Outdoor unit | Main PCB | Access to EEPROM failed due to some cause after outdoor unit started. |
| Forecast of cause | | | External cause (Noise, temporary open, voltage drop) |
| | | | Main PCB failure |

Check point 1. Reset power supply and operate

Does error indication show again?

If no, go to "Check point 1-2".



Check point 2. Replace main PCB

Change main PCB.



End

Check point 1-2. Check external cause

- Check if temporary voltage drop was not generated.
- Check if momentary open was not generated.
- Check if ground is connection correctly or there are no related cables near the power line.



End

2-12. E: 63. Inverter error (Outdoor unit)

| | | | |
|--------------------|--------------|---------------------|---|
| Indicator | Indoor unit | Operation indicator | 6 time flash |
| | | Timer indicator | 3 time flash |
| | | Economy indicator | Continuous flash |
| | | Error code | E: 63 |
| Detective actuator | Outdoor unit | Inverter PCB | Error information received from inverter PCB |
| Forecast of cause | | | External cause |
| | | | Power supply to inverter PCB wiring disconnection or open |
| | | | Inverter PCB failure |

Check point 1. Turn the power on again?

Error displayed again?

If no, go to ["Check point 1-2"](#).



Check point 2. Check the wiring (power supply to inverter PCB)

- Connector and wiring connection state check
- Cable open check



Check point 3. Replace inverter PCB

Replace inverter PCB



End

Check point 1-2. Check external cause

- Check if temporary voltage drop was not generated.
- Check if momentary open was not generated.
- Check if ground is connection correctly or there are no related cables near the power line.



End

2-13. E: 64. PFC circuit error (Outdoor unit)

| | | | |
|--------------------|--------------|---------------------|---|
| Indicator | Indoor unit | Operation indicator | 6 time flash |
| | | Timer indicator | 4 time flash |
| | | Economy indicator | Continuous flash |
| | | Error code | E: 64 |
| Detective actuator | Outdoor unit | Main PCB | <ul style="list-style-type: none"> When inverter input DC voltage is higher than 415 V for over 3 seconds, the compressor stops. If the same operation is repeated 5 times, the compressor stops permanently. |
| Forecast of cause | | | External cause |
| | | | Connector connection failure |
| | | | Main PCB failure |

Check point 1. Check external cause at indoor and outdoor (Voltage drop or Noise)

- Instant drop: Check if there is a large load electric apparatus in the same circuit.
- Momentary power failure: Check if there is a defective contact or leak current in the power supply circuit.
- Noise: Check if there is any equipment causing harmonic wave near electric line. (Neon bulb or electric equipment that may cause harmonic wave)
Check the complete insulation of grounding.



Check point 2. Check connection of Connector

- Check if connector is removed.
- Check erroneous connection.
- Check if cable is open.

→ Upon correcting the removed connector or mis-wiring, reset the power.



Check point 3. Replace main PCB

If check point 1 to 2 do not improve the symptom, change main PCB.



End

2-14. E: 71. Discharge thermistor error (Outdoor unit)

| | | | |
|--------------------|---------------------------------------|--|------------------|
| Indicator | Indoor unit | Operation indicator | 7 time flash |
| | | Timer indicator | 1 time flash |
| | | Economy indicator | Continuous flash |
| | | Error code | E: 71 |
| Detective actuator | Outdoor unit main PCB | When discharge pipe temperature thermistor open or short circuit is detected at power on or while running the compressor | |
| | Discharge pipe temperature thermistor | | |
| Forecast of cause | | Connector failure | |
| | | Thermistor failure | |
| | | Main PCB failure | |

Check point 1. Check connection of connector


- Check if connector is loose or removed.
- Check erroneous connection.
- Check if thermistor cable is open

→ Reset power when reinstalling due to removed connector or incorrect wiring.



Check point 2. Remove connector and check thermistor resistance value

- For the discharge temperature thermistor resistance value, refer to "[Thermistor resistance values](#)" on page 03-70.
- If thermistor is either open or shorted, replace it and reset the power.



Check point 3. Check voltage of main PCB

Make sure circuit diagram of outdoor unit and check terminal voltage at thermistor (DC 5.0 V).

NOTE: For details of thermistor connector, refer to "[Wiring diagrams](#)" in Chapter 2. TECHNICAL DATA AND PARTS LIST on page 02-14.
If the voltage does not appear, replace main PCB.



End

2-15. E: 73. Outdoor unit heat exchanger thermistor error (Outdoor unit)

| | | | |
|--------------------|---------------------------------------|---------------------|--|
| Indicator | Indoor unit | Operation indicator | 7 time flash |
| | | Timer indicator | 3 time flash |
| | | Economy indicator | Continuous flash |
| | | Error code | E: 73 |
| Detective actuator | Outdoor unit main PCB | | When heat exchanger temperature thermistor open or short circuit is detected at power on or while running the compressor |
| | Heat exchanger temperature thermistor | | |
| Forecast of cause | | | Connector failure |
| | | | Thermistor failure |
| | | | Main PCB failure |

Check point 1. Check connection of connector


- Check if connector is loose or removed.
- Check erroneous connection.
- Check if thermistor cable is open

→ Reset power when reinstalling due to removed connector or incorrect wiring.



Check point 2. Remove connector and check thermistor resistance value

- For the outdoor unit heat exchanger thermistor resistance value, refer to "[Thermistor resistance values](#)" on page 03-70.
- If thermistor is either open or shorted, replace it and reset the power.



Check point 3. Check voltage of main PCB

Make sure circuit diagram of outdoor unit and check terminal voltage at thermistor (DC 5.0 V).

NOTE: For details of thermistor connector, refer to "[Wiring diagrams](#)" in Chapter 2. TECHNICAL DATA AND PARTS LIST on page 02-14.

If the voltage does not appear, replace main PCB.



End

2-16. E: 74. Outdoor temperature thermistor error (Outdoor unit)

| | | | |
|--------------------|--------------------------------|---|------------------|
| Indicator | Indoor unit | Operation indicator | 7 time flash |
| | | Timer indicator | 4 time flash |
| | | Economy indicator | Continuous flash |
| | | Error code | E: 74 |
| Detective actuator | Outdoor unit main PCB | When outdoor temperature thermistor open or short circuit is detected at power on or while running the compressor | |
| | Outdoor temperature thermistor | | |
| Forecast of cause | | Connector failure | |
| | | Thermistor failure | |
| | | Main PCB failure | |

Check point 1. Check connection of connector


- Check if connector is loose or removed.
- Check erroneous connection.
- Check if thermistor cable is open

-> Reset power when reinstalling due to removed connector or incorrect wiring.



Check point 2. Remove connector and check thermistor resistance value

- For the outdoor temperature thermistor resistance value, refer to "[Thermistor resistance values](#)" on page 03-70.
- If thermistor is either open or shorted, replace it and reset the power.



Check point 3. Check voltage of main PCB

Make sure circuit diagram of outdoor unit and check terminal voltage at thermistor (DC 5.0 V).

NOTE: For details of thermistor connector, refer to "[Wiring diagrams](#)" in Chapter 2. TECHNICAL DATA AND PARTS LIST on page 02-14.

If the voltage does not appear, replace main PCB.



End

2-17. E: 84. Current sensor error (Outdoor unit)

| | | | |
|--------------------|--------------|---------------------|--|
| Indicator | Indoor unit | Operation indicator | 8 time flash |
| | | Timer indicator | 4 time flash |
| | | Economy indicator | Continuous flash |
| | | Error code | E: 84 |
| Detective actuator | Outdoor unit | main PCB | When input current sensor has detected 0 A, while inverter compressor is operating at higher than 56 rps, after 1 minute upon starting the compressor. (Except during the defrost operation) |
| Forecast of cause | | | Defective connection of electric components |
| | | | External cause |
| | | | Main PCB failure |

Check point 1. Reset power supply and operate

Does error indication show again?

If no, go to "Check point 1-2".



Check point 2. Check connections of outdoor unit electrical components

- Check if the terminal connection is loose.
- Check if connector is removed.
- Check erroneous connection.
- Check if cable is open.

Upon correcting the removed connector or miswiring, reset the power.



Check point 3. Replace main PCB

If Check point 1, 2 do not improve the symptom, change main PCB.



End

Check point 1-2. Check external cause at Indoor and Outdoor (Voltage drop or Noise)

- Instant drop: Check if there is a large load electric apparatus in the same circuit.
- Momentary power failure: Check if there is a defective contact or leak current in the power supply circuit.
- Noise: Check if there is any equipment causing harmonic wave near electric line. (Neon bulb or electric equipment that may cause harmonic wave)
Check the complete insulation of grounding.



End

2-18. E: 94. Trip detection (Outdoor unit)

| | | | |
|--------------------|--------------|---------------------|---|
| Indicator | Indoor unit | Operation indicator | 9 time flash |
| | | Timer indicator | 4 time flash |
| | | Economy indicator | Continuous flash |
| | | Error code | E: 94 |
| Detective actuator | Outdoor unit | Main PCB | Protection stop by over-current generation after inverter compressor start processing completed generated consecutively 10 times. NOTE: The number of generations is reset when the compressor starts up. |
| | | Compressor | |
| Forecast of cause | | | Outdoor unit fan operation defective, foreign matter on heat-exchanger, excessive rise of ambient temperature |
| | | | Main PCB failure |
| | | | Inverter compressor failure (lock, winding short) |

Check point 1. Check the outdoor unit fan operation, heat-exchanger, ambient temperature

- No obstructions in air passages?
- Heat exchange fins clogged
- Outdoor unit fan motor check
- Ambient temperature not raised by the effect of other heat sources?
- Discharged air not sucked in?



Check point 2. Replace main PCB

If Check point 1 do not improve the symptom, change main PCB.



Check point 3. Replace compressor

If Check point 2 do not improve the symptom, change compressor.



End

2-19. E: 95. Compressor motor control error (Outdoor unit)

| | | | |
|--------------------|--------------|---------------------|---|
| Indicator | Indoor unit | Operation indicator | 9 time flash |
| | | Timer indicator | 5 time flash |
| | | Economy indicator | Continuous flash |
| | | Error code | E: 95 |
| Detective actuator | Outdoor unit | Main PCB | <div>1. When running the compressor, if the detected rotor location is out of phase with actual rotor location more than 90°, the compressor stops.</div> <div>2. After the compressor restarts, if the same operation is repeated within 40 seconds, the compressor stops again.</div> <div>3. If 1. and 2. repeats 5 times, the compressor stops permanently.</div> |
| | | Compressor | |
| Forecast of cause | | | Defective connection of electric components |
| | | | Main PCB failure |
| | | | Compressor failure |

Check point 1. Check Noise from Compressor

Turn on Power and check operation noise.
→ If an abnormal noise show, replace compressor.



Check point 2. Check connection of around the compressor components

For compressor terminal, main PCB

- Check if connector is removed.
- Check erroneous connection.
- Check if cable is open. (Refer to inverter compressor in ["Service parts information"](#) on page 03-64.)

→ Upon correcting the removed connector or mis-wiring, reset the power.



Check point 3. Replace main PCB

If Check point 1, 2 do not improve the symptom, change main PCB.



Check point 4. Replace compressor

If Check point 3 do not improve the symptom, change compressor.



End

2-20. E: 97. Outdoor unit fan motor error (Outdoor unit)

| | | | |
|--------------------|--------------|---------------------|--|
| Indicator | Indoor unit | Operation indicator | 9 time flash |
| | | Timer indicator | 7 time flash |
| | | Economy indicator | Continuous flash |
| | | Error code | E: 97 |
| Detective actuator | Outdoor unit | Main PCB | <div>1. When outdoor fan rotation speed is less than 100 rpm in 20 seconds after fan motor starts, fan motor stops.</div> <div>2. After fan motor restarts, if the same operation within 60 seconds is repeated 3 times in a row, compressor and fan motor stops.</div> <div>3. If 1. and 2. repeats 5 times in a row, compressor and fan motor stops permanently.</div> |
| | | Fan motor | |
| Forecast of cause | | | Fan rotation failure |
| | | | Motor protection by surrounding temperature rise |
| | | | Main PCB failure |
| | | | Outdoor unit fan motor |

Check point 1. Check rotation of fan

Rotate the fan by hand when operation is off. (Check if fan is caught, dropped off or locked motor)
→ If fan or bearing is abnormal, replace it.



Check point 2. Check ambient temp. around motor

Check excessively high temperature around the motor. (If there is any surrounding equipment that causes heat)
Upon the temperature coming down, restart operation.




Check point 3. Check outdoor unit fan motor

Check outdoor unit fan motor. (Refer to outdoor unit fan motor in "[Service parts information](#)" on page 03-64.)
→ If outdoor unit fan motor is abnormal, replace outdoor unit fan motor and main PCB.



Check point 4. Check output voltage of main PCB

Check outdoor unit circuit diagram and the voltage. (Measure at main PCB side connector)



NOTE: For details of wiring diagram, refer to "[Wiring diagrams](#)" in Chapter 2. TECHNICAL DATA AND PARTS LIST on page 02-14.

| Read wire | DC voltage |
|-------------|-----------------|
| Red—Black | 240 V — 400 V |
| White—Black | 13.5 V — 16.5 V |

-> If the voltage is not correct, replace Main PCB.



End

2-21. E: 99. 4-way valve error (Outdoor unit)

| | | | |
|--------------------|---------------------------------------|---------------------|---|
| Indicator | Indoor unit | Operation indicator | 9 time flash |
| | | Timer indicator | 9 time flash |
| | | Economy indicator | Continuous flash |
| | | Error code | E: 99 |
| Detective actuator | Indoor unit | main PCB | When the indoor heat exchanger temperature is compared with the room temperature, and either following condition is detected continuously two times, the compressor stops. Indoor heat exchanger temp. - Room temp. > 20 °F (10 °C) (Cooling or Dry operation) Indoor heat exchanger temp. - Room temp. < -20 °F (-10 °C) (Heating operation) If the same operation is repeated 5 times, the compressor stops permanently. |
| | Heat exchanger temperature thermistor | | |
| | Room temperature thermistor | | |
| | 4-way valve | | |
| Forecast of cause | | | Connector connection failure |
| | | | Thermistor failure |
| | | | Coil failure |
| | | | 4-way valve failure |
| | | | Main PCB failure |

Check point 1. Check connection of connector

- Check if connector is removed.
- Check erroneous connection.
- Check if thermistor cable is open.

→ Upon correcting the removed connector or mis-wiring, reset the power.



Check point 2. Check each thermistor

- Isn't it fallen off the holder?
- Is there a cable pinched?

Check characteristics of room thermistor and indoor unit heat exchanger thermistor.

For the thermistor resistance value, refer to "[Thermistor resistance values](#)" on page 03-70.

→ If defective, replace the thermistor.



Check point 3. Check the solenoid coil and 4-way valve

- **Solenoid coil**
Remove CN30 from PCB and check the resistance value of coil. Resistance value is 1.88 kΩ — 2.29 kΩ (at 68 °F (20 °C)).
→ If it is open or abnormal resistance value, replace solenoid coil.
- **4-way valve**
Check each piping temperature, and the location of the valve by the temperature difference.
If the value location is not proper, replace 4-way valve.



Check point 4. Check the voltage of 4-way valve

- Check the voltage CN30 of Main PCB.
→ Check if AC 187 V (AC 208 V -10%) to AC 253 V (AC 230 V +10%) appears at CN30 of Main PCB.
- **Heating operation**
→ If it is not voltage, Replace Main PCB.
 - **Cooling operation**
→ If it is voltage, Replace Main PCB.



Check point 5. Replace main PCB

If Check Point 1 to 4 do not improve the symptom, replace main PCB.



End

2-22. E: A1. Discharge temperature error (Outdoor unit)

| | | | |
|--------------------|----------------------------------|--|------------------|
| Indicator | Indoor unit | Operation indicator | 10 time flash |
| | | Timer indicator | 1 time flash |
| | | Economy indicator | Continuous flash |
| | | Error code | E: A1 |
| Detective actuator | Outdoor unit main PCB | Protection stop by discharge temperature $\geq 230^{\circ}\text{F}$ (110°C) during compressor operation generated 2 times within 24 hours. | |
| | Discharge temperature thermistor | | |
| Forecast of cause | | 3-way valve not opened | |
| | | EEV defective, strainer clogged | |
| | | Outdoor unit operation failure, foreign matter on heat exchanger | |
| | | Discharge temperature thermistor failure | |
| | | Insufficient refrigerant | |
| | | Main PCB failure | |

Check point 1. Check if 3-way valve is open

If the 3-way valve is closed, open the 3-way valve and check operation.

NOTE: For cooling operation, check gas side of the 3-way valve.
For heating operation, check liquid side of the 3-way valve.



Check point 2. Check the electronic expansion valve (EEV) and strainer

- Check if EEV open.
Refer to outdoor unit Electronic Expansion Valve (EEV) in ["Service parts information"](#) on page 03-64.
- Check the strainer clogging.



Check point 3. Check the outdoor unit fan and heat exchanger

- Check for foreign object at heat exchanger
- Check if fan can be rotated by hand.
- Check the motor. (Refer to outdoor unit fan motor in ["Service parts information"](#) on page 03-64.)



Check point 4. Check the discharge thermistor

The discharge temperature thermistor characteristics check. (Check by disconnecting thermistor from PCB.)

NOTE: For the characteristics of the thermistor, refer to ["Thermistor resistance values"](#) on page 03-70.



Check point 5. Check the refrigerant amount

Check the refrigerant leakage.



Check point 6. Replace main PCB

If check point 1 to 5 do not improve the symptom, replace the main PCB.



End

3. Troubleshooting without error code

3-1. Indoor unit—No power

| | |
|-------------------|---------------------------------|
| Forecast of cause | Power supply failure |
| | External cause |
| | Electrical components defective |

Check point 1. Check installation condition

- Isn't the breaker down?
- Check loose or removed connection cable.

-> If abnormal condition is found, correct it by referring to the installation manual or the "DESIGN & TECHNICAL MANUAL".



Check point 2. Check external cause at indoor and outdoor (voltage drop or noise)

- Instant drop: Check if there is a large load electric apparatus in the same circuit.
- Momentary power failure: Check if there is a defective contact or leak current in the power supply circuit.
- Noise: Check if there is any equipment causing harmonic wave near electric line. (Neon bulb or electric equipment that may cause harmonic wave)
Check the complete insulation of grounding.



Check point 3. Check electrical components

Check the voltage of power supply.

Check if AC 187 to 253 V appears at outdoor unit terminal L—N.

-> If no, go to "[Check point 1](#)" and "[Check point 2](#)".



- Check fuse in filter PCB.
If fuse is open, check if the wiring between terminal and filter PCB is loose, and replace fuse.
- Check varistor in filter PCB.
If varistor is defective, there is a possibility of an abnormal power supply.
Check the correct power supply and replace varistor.
Upon checking the normal power supply, replace varistor.



End

3-2. Outdoor unit—No power

| | |
|-------------------|---------------------------------|
| Forecast of cause | Power supply failure |
| | External cause |
| | Electrical components defective |

Check point 1. Check installation condition

- Isn't the breaker down?
- Check loose or removed connection cable.

→ If abnormal condition is found, correct it by referring to the installation manual or the "DESIGN & TECHNICAL MANUAL".



Check point 2. Check external cause at indoor and outdoor (voltage drop or noise)

- Instant drop: Check if there is a large load electric apparatus in the same circuit.
- Momentary power failure: Check if there is a defective contact or leak current in the power supply circuit.
- Noise: Check if there is any equipment causing harmonic wave near electric line. (Neon bulb or electric equipment that may cause harmonic wave)
Check the complete insulation of grounding.




Check point 3. Check electrical components

Check the voltage of power supply.

Check if AC 187 to 253 V appears at outdoor unit terminal L - N

→ If no, go to "Check point 1" and "Check point 2".



- Check fuse in main PCB.
If fuse is open, check if the wiring between terminal and main PCB is loose, and replace fuse.
- Check varistor in main PCB.
If varistor is defective, there is a possibility of an abnormal power supply. Check the correct power supply and replace varistor.
→ Upon checking the normal power supply, replace varistor.



Check point 4. Replace main PCB

If check point 1 to 3 do not improve the symptom, change main PCB.



End

3-3. No operation (Power is on)

| | |
|-------------------|---------------------------------|
| Forecast of cause | Setting/ Connection failure |
| | External cause |
| | Electrical components defective |

Check point 1. Check indoor and outdoor installation condition

- Indoor unit:
 - Check incorrect wiring between indoor unit and remote controller.
 - Check if there is an open cable connection.
 - Are these indoor unit, outdoor unit, and remote controller suitable model numbers to connect?
- > If there is some abnormal condition, correct it by referring to the installation manual and "DESIGN & TECHNICAL MANUAL".



Turn off the power and check correct followings.

- Is there loose or removed communication line of indoor unit and outdoor unit?



Check point 2. Check external cause at indoor and outdoor (Voltage drop or Noise)

- Instant drop: Check if there is a large load electric apparatus in the same circuit.
- Momentary power failure: Check if there is a defective contact or leak current in the power supply circuit.
- Noise: Check if there is any equipment causing harmonic wave near electric line. (Neon bulb or electric equipment that may cause harmonic wave)
Check the complete insulation of grounding.



Check point 3. Check wired remote controller and controller PCB

Check voltage at CN2 (terminal 1—3) of UTY-TWBXF1(Communication kit).
(Power supply to remote controller)

- If it is DC 5 V, remote controller is failure. (The controller PCB is normal)
-> Replace remote controller.
- If it is DC 0 V, controller PCB is failure. (Check the remote controller once again)
-> Replace controller PCB.



Check point 4. Replace main PCB

If check point 1 to 3 do not improve the symptom, change main PCB.



End

3-4. No cooling/No heating

| | |
|-------------------|---|
| Forecast of cause | Indoor unit error |
| | Outdoor unit error |
| | Effect by surrounding environment |
| | Connection pipe/Connection wire failure |
| | Refrigeration cycle failure |

Check point 1. Check Indoor unit

- Does Indoor unit fan run in the HIGH mode?
- Is air filter dirty?
- Is heat exchanger clogged?
- Check if energy save function is operated.



Check point 2. Check outdoor unit operation

- Check if outdoor unit is operating.
- Check any objects that obstruct the air flow route.
- Check if heat exchanger is clogged.
- Is the valve open?



Check point 3. Check site condition

- Is capacity of Indoor unit fitted to the room size?
- Any windows open or direct sunlight?



Check point 4. Check Indoor/ Outdoor installation condition


- Check connection pipe (specified pipe length and pipe diameter?)
- Check any loose or removed communication line.

→ If there is an abnormal condition, correct it by referring to the installation manual or the "DESIGN & TECHNICAL MANUAL".



Check point 5. Check Refrigeration cycle

- Check if strainer is clogged (Refer to the figure below).
- Measure gas pressure, and if there is a leakage, correct it.
- Check the electronic expansion valve.
Refer to outdoor unit Electronic Expansion Valve (EEV) in "[Service parts information](#)" on page 03-64.
- Check compressor.
Refer to compressor in "[Service parts information](#)" on page 03-64.
Refer to inverter compressor in "[Service parts information](#)" on page 03-64.




NOTE: When recharging the refrigerant, make sure to perform vacuuming, and recharge the specified amount.




End

NOTES:

- Strainer normally does not have temperature difference between inlet and outlet as shown below.



- If there is a difference like shown below, there is a possibility of inside clogged. In this case, replace the strainer.



3-5. Abnormal noise

| | |
|-------------------|--|
| Forecast of cause | Abnormal installation (indoor unit/outdoor unit) |
| | Fan failure (indoor unit/outdoor unit) |
| | Compressor failure (outdoor) |

Diagnosis method when abnormal noise is occurred

Abnormal noise is coming from Indoor unit.
(Check and correct followings)



- Is main unit installed in stable condition?
- Is the installation of air suction grille and front panel normal?

↓

- Is fan broken or deformed?
- Is the screw of fan loose?
- Is there any object which obstruct the fan rotation?

↓

End

Abnormal noise is coming from Indoor unit.
(Check and correct followings)

↓

- Is main unit installed in stable condition?
- Is fan guard installed normally?

↓

- Is fan broken or deformed?
- Is the screw of fan loose?
- Is there any object which obstruct the fan rotation?

↓

Check if vibration noise by loose bolt or contact noise of piping is happening.

↓

Is compressor locked?


- Check Compressor
Refer to compressor and inverter compressor in "[Service parts information](#)" on page 03-64.

↓

End

3-6. Water leaking

| | |
|-------------------|------------------------|
| Forecast of cause | Erroneous installation |
| | Drain hose failure |



3-7. Too warm

| | |
|-------------------|--|
| Forecast of cause | House insulation setting has not been changed. |
| | Temperature sensing location has not been changed. |
| | Installation location of the wired remote. |
| | Function settings have not been changed. |

Check point 1. Check insulation level of structure of house

Is insulation level greater than R-13?

→ If no, go to "Check Point 4".



Check point 2. Check function setting

If insulation level is greater than R-13 set function 95 to 01.

NOTE: For details of function setting number 95, refer to "Function settings " in Chapter 5. FIELD WORKING on page 05-1.



Check Point 3. Check effects of function setting change

Is the space still too warm in relation to set point?



Check Point 4. Verify room temperature sensing location


Do you want room temperature sensed at the wired remote controller (Wired remote sensor) or by they build in sensor inside the unit (Indoor unit sensor)?

→ If indoor unit sensor, go to "Check Point 5".

→ If wired remote sensor, go to "Check point 8".

Check Point 5. Check the remote controller display

Is the "Thermo Sensor Icon" displayed on the screen?




→ If no, go to "Check point 7".



Check point 6. Check the remote controller

Hold down the THERMO SENSOR button until the thermo sensor icon is turned off.



→ If the space is still too warm, go to "Check point 7".



End

Check point 7. Check function settings

Using the table on the right adjust function 31. (Room Temperature Control for indoor unit sensor)


NOTE: For details of function setting number 31, refer to "Function settings" in Chapter 5. FIELD WORKING on page 05-1.



End

Check point 8. Check the remote controller display

Is the "Thermo Sensor Icon" displayed on the screen?



→ If no, go to "Check point 8-1".



Check point 9. Check the function Setting

Is function 48 (Room temperature sensor switching) set to 01?

→ If no, go to "Check point 9-1".



Check point 10. Location of the remote controller

Is the mounting location of the wired remote controller affecting the temperature sensing? (Sunlight on the remote, heat source next to the remote)

→ If no, go to "Check point 12".



Check point 11. Location of the remote controller

Move the remote controller.

→ If the space is still too warm, go to "Check point 12".



End

Check point 8-1. Check function setting


Is function 42 (Indoor room temperature sensor switching function) set to 01?

NOTE: For details of function setting number 42, refer to "Function settings" in Chapter 5. FIELD WORKING on page 05-1.



Check point 8-2. Check the remote controller

Press and hold down the THERMO SENSOR button to turn on the icon.



→ If the space is still too warm, go to "Check point 9".



End

Check point 9-1. Check function setting

Change setting of function 48 (Room temperature sensor switching) to 01.

NOTE: For details of function setting number 48, refer to "[Function settings](#) " in Chapter 5. FIELD WORKING on page 05-1.

**Check point 9-2. Check the effects of function setting change**

Did this function setting improve temperature control?

→ If the space is still too warm, go to "[Check point 10](#)".



End

Check point 12. Check function setting

Using the table on the right adjust temperature correction by changing function setting 36. (Room Temperature control for wired remote controller sensor)

NOTE: For details of function setting number 36, refer to "[Function settings](#) " in Chapter 5. FIELD WORKING on page 05-1.



End

3-8. Too cool

| | |
|-------------------|--|
| Forecast of cause | House insulation setting has not been changed. |
| | Temperature sensing location has not been changed. |
| | Installation location of the wired remote. |
| | Function settings have not been changed. |

Check point 1. Check insulation level of structure of house

Is insulation level greater than R-13?

→ If no, go to "Check Point 4".



Check point 2. Check function setting

If insulation level is greater than R-13 set function 95 to 01.

NOTE: For details of function setting number 95, refer to "Function settings " in Chapter 5. FIELD WORKING on page 05-1.



Check Point 3. Check effects of function setting change

Is the space still too cool in relation to set point?



Check Point 4. Verify room temperature sensing location


Do you want room temperature sensed at the wired remote controller (Wired remote sensor) or by they build in sensor inside the unit (Indoor unit sensor)?

→ If indoor unit sensor, go to "Check Point 5".

→ If wired remote sensor, go to "Check point 8".

Check Point 5. Check the remote controller display

Is the "Thermo Sensor Icon" displayed on the screen?



→ If no, go to "Check point 7".



Check point 10. Location of the remote controller

Is the mounting location of the wired remote controller affecting the temperature sensing? (Sunlight on the remote, heat source next to the remote)

→ If no, go to "Check point 12".



Check point 11. Location of the remote controller

Move the remote controller.

→ If the space is still too cool, go to "Check point 12".



End

Check point 8-1. Check function setting


Is function 42 (Indoor room temperature sensor switching function) set to 01?

NOTE: For details of function setting number 42, refer to "Function settings" in Chapter 5. FIELD WORKING on page 05-1.



Check point 8-2. Check the remote controller

Press and hold down the THERMO SENSOR button to turn on the icon.



→ If the space is still too cool, go to "Check point 9".



End

Check point 9-1. Check function setting

Change setting of function 48 (Room temperature sensor switching) to 01.

NOTE: For details of function setting number 48, refer to "[Function settings](#)" in Chapter 5. FIELD WORKING on page 05-1.

**Check point 9-2. Check the effects of function setting change**

Did this function setting improve temperature control?

→ If the space is still too cool, go to "[Check point 10](#)".



End

Check point 12. Check function setting

Using the table on the right adjust temperature correction by changing function setting 35. (Room Temperature control for wired remote controller sensor)


NOTE: For details of function setting number 35, refer to "[Function settings](#)" in Chapter 5. FIELD WORKING on page 05-1.



End

4. Troubleshooting with error code (For wireless LAN adapter)

4-1. E: 18. External communication error between indoor unit and WLAN adapter

| | | | |
|--------------------|--------------------------|---------------------|---|
| Indicator | Indoor unit | Operation indicator | 1 time flash |
| | | Timer indicator | 8 time flash |
| | | Economy indicator | Continuous flash |
| | | Error code | E: 18 |
| | Wireless LAN adapter | LED1 (green) | Flashing fast |
| LED2 (orange) | | On | |
| Detective actuator | Wireless LAN adapter PCB | | After receiving a signal from the wireless LAN adapter, the same signal has not been received for 15 seconds. |
| | Controller PCB | | |
| | | |  |
| Forecast of cause | | | Connection between indoor unit and wireless LAN adapter failure |
| | | | Wireless LAN adapter PCB failure |
| | | | Controller PCB failure |

Check point 1. Check the connection

- Check any loose or removed connection of between the wireless LAN adapter PCB and controller PCB.
-> If there is abnormal condition, correct it.
- Check the connection condition on the controller PCB.
-> If there is loose connector, open cable or mis-wiring, correct it.



Check point 2. Replace wireless LAN adapter.

If check point 1 do not improve the symptom, replace the wireless LAN adapter and cancel the registration of air conditioner on the mobile app.

After replacing the adapter, perform the pairing on the mobile app.

For the method of the mobile app, refer to ["Mobile app setting method"](#) on page 03-59.




Check point 3. Replace controller PCB

If check point 1 to 2 do not improve the symptom, replace the controller PCB.



End

4-2. Wireless LAN adapter error

| | | | |
|--------------------|-------------------------------------|---|---------------|
| Indicator | Indoor unit | Operation indicator | No indication |
| | | Timer indicator | No indication |
| | | Economy indicator | No indication |
| | | Error code | — |
| | Wireless LAN adapter | LED1 (green) | Flashing fast |
| | | LED2 (orange) | Flashing fast |
| Detective actuator | Wireless LAN adapter setting button | When the setting button becomes on for consecutive 60 seconds or more.  | |
| | Wireless LAN adapter PCB | | |
| Forecast of cause | | Wireless LAN adapter setting button failure | |
| | | Wireless LAN adapter PCB failure | |

Check point 1. Check the setting button

Check if setting button is kept pressed.

-> If the setting button is held down by the foreign matter, remove the foreign matter or remove the cause of the button press.



Check point 2. Replace wireless LAN adapter.

If check point 1 do not improve the symptom, replace the wireless LAN adapter and cancel the registration of air conditioner on the mobile app.

After replacing the adapter, perform the pairing on the mobile app.

For the method of the mobile app, refer to ["Mobile app setting method"](#) on page 03-59.




Check point 3. Replace controller PCB

If check point 1 to 2 do not improve the symptom, replace the Wireless LAN adapter.



End

4-3. Network communication error between wireless LAN router and WLAN adapter

| | | | |
|--------------------|--------------------------|--|---------------|
| Indicator | Indoor unit | Operation indicator | No indication |
| | | Timer indicator | No indication |
| | | Economy indicator | No indication |
| | | Error code | — |
| | Wireless LAN adapter | LED1 (green) | On |
| | | LED2 (orange) | Flashing fast |
| Detective actuator | Wireless LAN router | When the not connection between wireless LAN adapter and wireless LAN router. | |
| | Wireless LAN adapter PCB | | |
| Forecast of cause | |  | |
| | | Connection cable failure of wireless LAN router | |
| | | Connection between wireless LAN adapter and wireless LAN router failure | |
| | | Wireless LAN router failure | |
| | | Wireless LAN adapter PCB failure | |

Check point 1. Check the connection cable

Check the connection cable on the wireless LAN router.

-> If there is loose connector, open cable or mis-wiring, correct it.



Check point 2. Check the connection status.

Check the connection status to the internet and wireless LAN router.

-> If the wireless LAN router is not connected to the internet, check the transmission between wireless LAN products (ex. PC or game console, etc.) other than air conditioner and wireless LAN router.

If no, go to ["Check point 2-2"](#).



Check point 3. Turn on the power again of air conditioner.

If check point 1 to 2 do not improve the symptom, turn on the power of the air conditioner again and wait for 60 seconds.



Check point 4. Replace wireless LAN adapter.

If check point 3 do not improve the symptom, replace the wireless LAN adapter and cancel the registration of air conditioner on the mobile app.

After replacing the adapter, perform the pairing on the mobile app.

For the method of the mobile app, refer to "[Mobile app setting method](#)" on page 03-59.

**End****Check point 2-2. Check the transmission state**

Check the wireless transmission state of the wireless LAN router (LED status).

-> If the wireless transmission from the wireless LAN router has not been outgoing, inquire to the wireless LAN router maker.

**End**

4-4. E: 18. Communication error

| | | | |
|--------------------|---|--|------------------|
| Indicator | Indoor unit | Operation indicator | 1 time flash |
| | | Timer indicator | 8 time flash |
| | | Economy indicator | Continuous flash |
| | | Error code | E: 18 |
| | Wireless LAN adapter | LED1 (green) | Flashing fast |
| | | LED2 (orange) | Flashing fast |
| Detective actuator | Wireless LAN router | When the external communication error between indoor unit and WLAN adapter and network communication error between wireless LAN router and WLAN adapter has occurred simultaneously. | |
| | Wireless LAN adapter PCB | | |
| | Indoor unit controller PCB | | |
| | | | |
| Forecast of cause | Connection cable failure of wireless LAN router | | |
| | Wireless LAN router failure | | |
| | Connection between indoor unit and wireless LAN adapter failure | | |
| | Connection between wireless LAN adapter and wireless LAN router failure | | |
| | Wireless LAN adapter PCB failure | | |
| | Controller PCB failure | | |

Check point 1. Check the connection cable

Check the connection cable on the wireless LAN router.

-> If there is loose connector, open cable or mis-wiring, correct it.



Check point 2. Check the connection status and transmission state

- Check the connection status to the internet and wireless LAN router.
-> If the wireless LAN router is not connected to the internet, check the transmission between wireless LAN products (ex. PC or game console, etc.) other than air conditioner and wireless LAN router.
If no, go to ["Check point 4"](#).
- Check the wireless transmission state of wireless LAN router (LED status).
-> If the wireless transmission from the wireless LAN router has not been outgoing, inquire to wireless LAN router maker.

If the display pattern is changed as follows, go to ["Check point 3-2"](#).

- LED 1 (green): flashing fast
- LED 2 (orange): on

If no, go to ["Check point 3-1"](#).



Check point 3-1. Turn on the power again of air conditioner.

If check point 1 to 2 do not improve the symptom, turn on the power of the air conditioner again and wait for 60 seconds.

-> When the flashing pattern of the LED 2 (orange) is on, go to ["Check point 3-2"](#).

-> When the flashing pattern of the LED 2 (orange) is flashing fast, go to ["Check point 4"](#).

**Check point 3-2. Check the connection.**

- Check any loose or removed connection of between the wireless LAN adapter PCB and controller PCB.
-> If there is abnormal condition, correct it.
- Check the connection condition on the controller PCB.
-> If there is loose connector, open cable or mis-wiring, correct it.

**Check point 4. Replace wireless LAN adapter.**

If check point 2 to 3 do not improve the symptom, replace the wireless LAN adapter and cancel the registration of air conditioner on the mobile app.

After replacing the adapter, perform the pairing on the mobile app.

For the method of the mobile app, refer to ["Mobile app setting method"](#) on page 03-59.

**Check point 5. Replace controller PCB**

If check point 4 do not improve the symptom, replace the controller PCB.



End

4-5. E: 18. Wireless LAN adapter non-energized

| | | | |
|--------------------|----------------------------|---------------------|---|
| Indicator | Indoor unit | Operation indicator | 1 time flash |
| | | Timer indicator | 8 time flash |
| | | Economy indicator | Continuous flash |
| | | Error code | E: 18 |
| | Wireless LAN adapter | LED1 (green) | Off |
| | | LED2 (orange) | Off |
| Detective actuator | Indoor unit controller PCB | | When the voltage (DC 12 V) does not output from the controller PCB. |
| | Wireless LAN adapter PCB | | |
| Forecast of cause | | | Indoor unit controller PCB failure |
| | | | Wireless LAN adapter PCB failure |
| | | | Wiring connection failure |

Check point 1. Check the connection.

- Check any loose or removed connection of between the wireless LAN adapter PCB and controller PCB.
-> If there is abnormal condition, correct it.
- Check the connection condition on the controller PCB.
-> If there is loose connector, open cable or mis-wiring, correct it.



Check point 2. Check the wireless LAN adapter PCB and the controller PCB

Check voltage at CN6 (terminal 1—2) of main PCB.

(Power supply to remote controller)

- If it is DC 0 V, controller PCB is failure.
-> Replace controller PCB.
- If it is DC 12 V, wireless LAN adapter PCB is failure.
-> Replace the wireless LAN adapter and cancel the registration of air conditioner on the mobile app.

After replacing the adapter, perform the pairing on the mobile app.

For the method of the mobile app, refer to ["Mobile app setting method"](#) on page 03-59.



End

4-6. Wireless LAN adapter Sleep mode (Indoor unit)

| | | | |
|--------------------|----------------------|---------------------|--|
| Indicator | Indoor unit | Operation indicator | No indication |
| | | Timer indicator | No indication |
| | | Economy indicator | No indication |
| | | Error code | — |
| | Wireless LAN adapter | LED1 (green) | Off |
| | | LED2 (orange) | Off |
| Detective actuator | Sleep mode | | When the state in which fly a wireless(SSID) have passed 1 hour. |
| Forecast of cause | | | Sleep mode |

Check point 1. Cheak the sleep mode

Press the Wireless LAN adapter setting button the 3 seconds or more.

-> If the display pattern is changed as follows, refer to ["Network communication error between wireless LAN router and WLAN adapter"](#) on page 03-53.

- LED 1 (green): on
- LED 2 (orange): flashing fast

4-7. Mobile app setting method


■ Air conditioner deregistration method

When the wireless LAN adapter is replaced, deregistration of all air conditioner is necessary on the mobile app.


1. Launch the mobile app.




2. Press and hold the registered device name of the air conditioner.



3. If the Unregister button is displayed, tap the button.



4. Tap the Yes button.



5. Deregistration of the air conditioner is completed.

■ Air conditioner registration pairing method

Choose the following modes to connect the air conditioner to the wireless LAN router.

NOTES:

- Before starting this setting, wait for 60 seconds or more after the power supply is connected to the air conditioner (via breaker or plug).
- Check that the smartphone or tablet PC is linked to the wireless router to be connected to the air conditioner.
The setting does not work if the same wireless LAN router is not connected.
- The displayed screen design may differ depending on the version of the mobile app.
- To control 2 or more air conditioners with the same smartphone or tablet PC, repeat the setup of the chosen mode.


Lighting pattern: ○ Off ● On ☼ Flashing

● Button mode


1. Launch the mobile app.




2. Sign in with your E-mail address and password following the screen on the mobile app.



3. Press the + button to add a new air conditioner.




4. Confirm that LED 2 is flashing (On/Off at 2 seconds intervals). Then select Button mode on the screen. If LED 2 and 2 are off, push the setting button once.



5. Press the WPS button on the wireless LAN router to be connected.
For the button location of the wireless LAN router and how to press it, refer to the operation manual of the wireless LAN router.




6. Confirm LED 2 is flashing (On/Off at 2 seconds intervals). Then press and hold the setting button on the wireless LAN adapter for 3 seconds.



LED 2 lighting will change. (On/Off: 2 sec./2 sec. → 2 sec./0.5 sec.)
Confirm both of the LED 1 and 2 are on to proceed.

7. Press Register button to start the connection with the wireless LAN router.




Both of the LED 1 and 2 flash 2 times and a message appear when the setup is completed.

● Manual mode (For Android)

1. Launch the mobile app.




2. Sign in with your E-mail address and password following the screen on the mobile app.



3. Press the + button to add a new air conditioner.




4. Select manual mode.




If both of the LED 1 and 2 are off, push the setting button once.

5. Select the SSID of the air conditioner to be connected.




Input the PIN code written on the wireless LAN label.

6. Select the SSID of the wireless LAN router to be connected.



Input the wireless LAN router (wireless LAN access point) password then press Connect device button.

7. When setup is completed, both of the LED 1 and 2 flash 2 times, and a message appear.



● Manual mode (For iOS)

1. Launch the mobile app.




2. Sign in with your E-mail address and password following the screen on the mobile app.



3. Press the + button to add a new air conditioner.




4. Select manual mode.




If both of the LED 1 and 2 are off, push the setting button once.

5. Select Open W-LAN setting button or activate the wireless LAN by pressing the Home button → Setting button → Wi-Fi button.




Select the SSID of the air conditioner to be connected.

6. Input the PIN code written on the wireless LAN label.



7. Select the SSID of the wireless LAN router to be connected.
Input the wireless LAN router (wireless LAN access point) password then press Connective device button.




When setup is completed, both of the LED 1 and 2 flash 2 times and a message appear.

5. Service parts information

5-1. Compressor


Diagnosis method of compressor (If outdoor unit LED displays error, refer to troubleshooting)



5-2. Inverter compressor



Check point 1. Check connection

Check terminal connection of compressor.
(loose or incorrect wiring)



Check point 2. Check winding resistance

Check winding resistance of each terminal.
Resistance value: 1.916 Ω at 68 °F (20°C)



→ If the resistance value is 0 Ω or infinite, replace compressor.



Check point 3. Replace inverter PCB

If check point 1 to 2 do not improve the symptom, replace main PCB.

5-3. Outdoor unit Electronic Expansion Valve (EEV)


Check point 1. Check connections

Check connection of connector. (Loose connector or open cable)

NOTE: For details of wiring diagram, refer to "Wiring diagrams" in Chapter 2. TECHNICAL DATA AND PARTS LIST on page 02-14.

Check point 2. Check coil of EEV

Remove connector, check each winding resistance of coil.

| Read wire | Resistance value |
|--------------------|---|
| 1 (Red)—2 (Blue) | $46 \Omega \pm 4 \Omega$ at 68°F (20°C)  |
| 1 (Red)—3 (Orange) | |
| 1 (Red)—4 (Yellow) | |
| 1 (Red)—5 (White) | |

→ If Resistance value is abnormal, replace EEV.

Check point 3. Check Voltage from main PCB

Remove connector and check voltage (DC 12 V)

→ If it does not appear, replace main PCB.



Check point 4. Check noise at start up


Turn on the power and check the operation noise.

→ If an abnormal noise does not show, replace main PCB.

Check point 5. Check Opening and Closing Operation of Valve


When valve is closed, it has a temp. difference between inlet and outlet

CLOSE
Example : Hot Gas




If it is open, it has no temp. difference between inlet and outlet

OPEN
Example : Hot Gas




Check point 6. Check strainer

- Strainer normally does not have temperature difference between inlet and outlet as shown below.



- If there is a difference like shown below, there is a possibility of inside clogged. In this case, replace the strainer.



5-4. Indoor unit fan motor

Check point 1. Check rotation of fan

Rotate the fan by hand when operation is off.
 (Check if fan is caught, dropped off or locked motor)
 → If fan or bearing is abnormal, replace it.


Check point 2. Check resistance of indoor fan motor

Refer to below. Circuit-test “Vm” and “GND” terminal

NOTE: Vm: DC voltage, GND: Earth terminal

→ If they are short-circuited (below 300 kΩ), replace indoor fan motor and controller PCB.

| Pin number (wire color) | Terminal function (symbol) |
|----------------------------|-------------------------------|
| 1 (Red) | DC voltage (Vm) |
| 2 | No function |
| 3 | No function |
| 4 (Black) | Earth terminal (GND) |
| 5 (White) | Control voltage (Vcc) |
| 6 (Yellow) | Speed command (Vsp) |
| 7 (Brown)) | Feed back (FG) |



5-5. Outdoor unit fan motor

Check point 1. Check rotation of fan

Rotate the fan by hand when operation is off.
 (Check if fan is caught, dropped off or locked motor)
 → If fan or bearing is abnormal, replace it.


Check point 2. Check resistance of outdoor fan motor

Refer to below. Circuit-test “Vm” and “GND” terminal

NOTE: Vm: DC voltage, GND: Earth terminal

→ If they are short-circuited (below 300 kΩ), replace outdoor fan motor and controller PCB.

| Pin number (wire color) | Terminal function (symbol) |
|----------------------------|-------------------------------|
| 1 (Red) | DC voltage (Vm) |
| 2 | No function |
| 3 | No function |
| 4 (Black) | Earth terminal (GND) |
| 5 (White) | Control voltage (Vcc) |
| 6 (Yellow) | Speed command (Vsp) |
| 7 (Brown)) | Feed back (FG) |



6. Thermistor resistance values

6-1. Indoor unit

■ Room temperature thermistor

| Temperature °F (°C) | Resistance (kΩ) | Voltage (V) |
|---------------------|-----------------|-------------|
| 14.0 (-10.0) | 58.25 | 0.73 |
| 23.0 (-5.0) | 44.03 | 0.93 |
| 32.0 (0.0) | 33.62 | 1.15 |
| 41.0 (5.0) | 25.93 | 1.39 |
| 50.0 (10.0) | 20.18 | 1.66 |
| 59.0 (15.0) | 15.84 | 1.94 |
| 68.0 (20.0) | 12.54 | 2.22 |
| 77.0 (25.0) | 10.00 | 2.50 |
| 86.0 (30.0) | 8.04 | 2.77 |
| 95.0 (35.0) | 6.51 | 3.03 |
| 104.0 (40.0) | 5.30 | 3.27 |
| 113.0 (45.0) | 4.35 | 3.49 |

■ Heat exchanger temperature thermistor

| Temperature °F (°C) | Resistance (kΩ) | Voltage (V) |
|---------------------|-----------------|-------------|
| -22.0 (-30.0) | 1,131.91 | 0.21 |
| -13.0 (-25.0) | 804.52 | 0.29 |
| -4.0 (-20.0) | 579.59 | 0.40 |
| 5.0 (-15.0) | 422.89 | 0.53 |
| 14.0 (-10.0) | 312.27 | 0.69 |
| 23.0 (-5.0) | 233.21 | 0.88 |
| 32.0 (0.0) | 176.03 | 1.10 |
| 41.0 (5.0) | 134.23 | 1.36 |
| 50.0 (10.0) | 103.34 | 1.63 |
| 59.0 (15.0) | 80.28 | 1.92 |
| 68.0 (20.0) | 62.91 | 2.21 |
| 77.0 (25.0) | 49.70 | 2.51 |
| 86.0 (30.0) | 39.57 | 2.79 |
| 95.0 (35.0) | 31.74 | 3.06 |
| 104.0 (40.0) | 25.64 | 3.30 |
| 113.0 (45.0) | 20.85 | 3.53 |
| 122.0 (50.0) | 17.06 | 3.73 |
| 131.0 (55.0) | 14.05 | 3.90 |
| 140.0 (60.0) | 11.64 | 4.02 |
| 149.0 (65.0) | 9.69 | 4.19 |

6-2. Outdoor unit

■ Discharge temperature thermistor

| Temperature °F (°C) | Resistance (kΩ) | Voltage (V) |
|---------------------|-----------------|-------------|
| -22.0 (-30.0) | 1,013.11 | 0.06 |
| -12.0 (-25.0) | 729.09 | 0.09 |
| -4.0 (-20.0) | 531.56 | 0.12 |
| 5.0 (-15.0) | 392.31 | 0.16 |
| 14.0 (-10.0) | 292.91 | 0.21 |
| 23.0 (-5.0) | 221.09 | 0.28 |
| 32.0 (0.0) | 168.60 | 0.36 |
| 41.0 (5.0) | 129.84 | 0.46 |
| 50.0 (10.0) | 100.91 | 0.57 |
| 59.0 (15.0) | 79.12 | 0.71 |
| 68.0 (20.0) | 62.55 | 0.86 |
| 77.0 (25.0) | 49.84 | 1.03 |
| 86.0 (30.0) | 40.01 | 1.23 |
| 95.0 (35.0) | 32.35 | 1.43 |
| 104.0 (40.0) | 26.34 | 1.65 |
| 113.0 (45.0) | 21.58 | 1.88 |
| 122.0 (50.0) | 17.79 | 2.11 |
| 131.0 (55.0) | 14.75 | 2.34 |
| 140.0 (60.0) | 12.30 | 2.57 |
| 149.0 (65.0) | 10.32 | 2.79 |
| 158.0 (70.0) | 8.70 | 3.00 |
| 167.0 (75.0) | 7.36 | 3.19 |
| 176.0 (80.0) | 6.27 | 3.37 |
| 185.0 (85.0) | 5.36 | 3.54 |
| 194.0 (90.0) | 4.60 | 3.69 |
| 203.0 (95.0) | 3.96 | 3.83 |
| 212.0 (100.0) | 3.43 | 3.96 |
| 221.0 (105.0) | 2.98 | 4.07 |
| 230.0 (110.0) | 2.60 | 4.17 |
| 239.0 (115.0) | 2.27 | 4.26 |
| 248.0 (120.0) | 2.00 | 4.33 |

■ Compressor temperature thermistor

| Temperature °F (°C) | Resistance (kΩ) | Voltage (V) |
|---------------------|-----------------|-------------|
| -22.0 (-30.0) | 1,013.11 | 0.06 |
| -12.0 (-25.0) | 729.09 | 0.09 |
| -4.0 (-20.0) | 531.56 | 0.12 |
| 5.0 (-15.0) | 392.31 | 0.16 |
| 14.0 (-10.0) | 292.91 | 0.21 |
| 23.0 (-5.0) | 221.09 | 0.28 |
| 32.0 (0.0) | 168.60 | 0.36 |
| 41.0 (5.0) | 129.84 | 0.46 |
| 50.0 (10.0) | 100.91 | 0.57 |
| 59.0 (15.0) | 79.12 | 0.71 |
| 68.0 (20.0) | 62.55 | 0.86 |
| 77.0 (25.0) | 49.84 | 1.03 |
| 86.0 (30.0) | 40.01 | 1.23 |
| 95.0 (35.0) | 32.35 | 1.43 |
| 104.0 (40.0) | 26.34 | 1.65 |
| 113.0 (45.0) | 21.58 | 1.88 |
| 122.0 (50.0) | 17.79 | 2.11 |
| 131.0 (55.0) | 14.75 | 2.34 |
| 140.0 (60.0) | 12.30 | 2.57 |
| 149.0 (65.0) | 10.32 | 2.79 |
| 158.0 (70.0) | 8.70 | 3.00 |
| 167.0 (75.0) | 7.36 | 3.19 |
| 176.0 (80.0) | 6.27 | 3.37 |
| 185.0 (85.0) | 5.36 | 3.54 |
| 194.0 (90.0) | 4.60 | 3.69 |
| 203.0 (95.0) | 3.96 | 3.83 |
| 212.0 (100.0) | 3.43 | 3.96 |
| 221.0 (105.0) | 2.98 | 4.07 |
| 230.0 (110.0) | 2.60 | 4.17 |
| 239.0 (115.0) | 2.27 | 4.26 |
| 248.0 (120.0) | 2.00 | 4.33 |

TROUBLESHOOTING

TROUBLESHOOTING

■ Heat exchanger temperature thermistor

| Temperature °F (°C) | Resistance (kΩ) | Voltage (V) |
|---------------------|-----------------|-------------|
| -22.0 (-30.0) | 95.58 | 0.24 |
| -12.0 (-25.0) | 68.90 | 0.32 |
| -4.0 (-20.0) | 50.31 | 0.43 |
| 5.0 (-15.0) | 37.19 | 0.57 |
| 14.0 (-10.0) | 27.81 | 0.73 |
| 23.0 (-5.0) | 21.02 | 0.92 |
| 32.0 (0.0) | 16.05 | 1.14 |
| 41.0 (5.0) | 12.38 | 1.39 |
| 50.0 (10.0) | 9.63 | 1.65 |
| 59.0 (15.0) | 7.56 | 1.93 |
| 68.0 (20.0) | 5.98 | 2.21 |
| 77.0 (25.0) | 4.77 | 2.49 |
| 86.0 (30.0) | 3.84 | 2.77 |
| 95.0 (35.0) | 3.11 | 3.02 |
| 104.0 (40.0) | 2.53 | 3.26 |
| 113.0 (45.0) | 2.08 | 3.48 |
| 122.0 (50.0) | 1.71 | 3.68 |
| 131.0 (55.0) | 1.42 | 3.85 |
| 140.0 (60.0) | 1.19 | 4.00 |
| 149.0 (65.0) | 1.00 | 4.13 |
| 158.0 (70.0) | 0.84 | 4.25 |
| 167.0 (75.0) | 0.71 | 4.35 |
| 176.0 (80.0) | 0.61 | 4.43 |

■ Outdoor temperature thermistor

| Temperature °F (°C) | Resistance (kΩ) | Voltage (V) |
|---------------------|-----------------|-------------|
| -22.0 (-30.0) | 224.33 | 0.73 |
| -12.0 (-25.0) | 159.71 | 0.97 |
| -4.0 (-20.0) | 115.24 | 1.25 |
| 5.0 (-15.0) | 84.21 | 1.56 |
| 14.0 (-10.0) | 62.28 | 1.90 |
| 23.0 (-5.0) | 46.58 | 2.26 |
| 32.0 (0.0) | 35.21 | 2.61 |
| 41.0 (5.0) | 26.88 | 2.94 |
| 50.0 (10.0) | 20.72 | 3.25 |
| 59.0 (15.0) | 16.12 | 3.52 |
| 68.0 (20.0) | 12.64 | 3.76 |
| 77.0 (25.0) | 10.00 | 3.97 |
| 86.0 (30.0) | 7.97 | 4.14 |
| 95.0 (35.0) | 6.40 | 4.28 |
| 104.0 (40.0) | 5.18 | 4.41 |
| 113.0 (45.0) | 4.21 | 4.51 |
| 122.0 (50.0) | 3.45 | 4.59 |
| 131.0 (55.0) | 2.85 | 4.65 |

4. CONTROL AND FUNCTIONS

CONTENTS

4. CONTROL AND FUNCTIONS

| | |
|---|--------------|
| 1. Compressor frequency control | 04-1 |
| 1-1. Cooling operation | 04-1 |
| 1-2. Heating operation | 04-3 |
| 1-3. Dry operation | 04-4 |
| 1-4. Compressor frequency at normal start-up | 04-4 |
| 1-5. Compressor frequency limitation by outdoor temperature | 04-5 |
| 2. Auto changeover operation | 04-7 |
| 3. Fan control | 04-9 |
| 3-1. Indoor fan control | 04-9 |
| 3-2. Outdoor fan control | 04-13 |
| 4. Louver control | 04-16 |
| 4-1. Vertical airflow direction louver control | 04-16 |
| 4-2. Horizontal airflow direction louver control | 04-16 |
| 4-3. Swing operation | 04-17 |
| 5. Timer operation control | 04-18 |
| 5-1. Wireless remote control | 04-18 |
| 5-2. Wired remote control | 04-20 |
| 6. Defrost operation control | 04-23 |
| 6-1. Defrost operation in heating operation stopped | 04-24 |
| 7. Various control | 04-25 |
| 7-1. Auto restart | 04-25 |
| 7-2. MANUAL AUTO operation | 04-25 |
| 7-3. Forced cooling operation | 04-26 |
| 7-4. 10 °C HEAT operation | 04-26 |
| 7-5. ECONOMY operation | 04-26 |
| 7-6. POWERFUL operation | 04-27 |
| 7-7. Compressor preheating | 04-27 |
| 7-8. Electronic expansion valve control | 04-27 |
| 7-9. Prevention to restart for 3 minutes (3 minutes st) | 04-28 |
| 7-10. 4-way valve control | 04-28 |
| 7-11. Outdoor unit low noise operation | 04-28 |
| 8. Various protections | 04-29 |
| 8-1. Discharge gas temperature over-rise prevention control | 04-29 |
| 8-2. Anti-freezing control (cooling and dry mode) | 04-29 |
| 8-3. Current release control | 04-30 |
| 8-4. Cooling pressure over-rise protection | 04-30 |
| 8-5. Low outdoor temperature protection | 04-30 |
| 8-6. High temperature and high pressure release control | 04-31 |

1. Compressor frequency control

1-1. Cooling operation


A sensor (room temperature thermistor) built in the indoor unit body will usually perceive difference or variation between a set temperature and present room temperature, and controls the operation frequency of the compressor.

- If the room temperature is 6.0 °C higher than a set temperature, the compressor operation frequency will attain to maximum performance.
- If the room temperature is 1.0 °C lower than a set temperature, the compressor will be stopped.
- When the room temperature is within the range of +6.0°C to -1.0°C of the setting temperature, the compressor frequency is controlled within the range shown in the table below. However, the maximum frequency is limited in the range shown in the figure below based on the indoor fan mode and the outdoor temperature.

- **Compressor frequency range**

| Model name | Minimum frequency | Maximum frequency |
|------------|-------------------|-------------------|
| ASUG09LZAS | 8 rps | 58 rps |
| ASUG12LZAS | 8 rps | 74 rps |
| ASUG15LZAS | 8 rps | 80 rps |

- Limit of maximum speed based on outdoor temperature



Unit: rps

| Model name | Outdoor temperature zone | Indoor unit fan mode | | | |
|------------|--------------------------|----------------------|-----|-----|-------|
| | | HIGH | MED | LOW | QUIET |
| ASUG09LZAS | A zone | 58 | 42 | 30 | 24 |
| | B zone | 58 | 42 | 30 | 24 |
| | C zone | 58 | 42 | 30 | 24 |
| | D zone | 50 | 34 | 26 | 20 |
| | E zone | 50 | 34 | 26 | 20 |
| | F zone | 50 | 34 | 26 | 20 |
| ASUG12LZAS | A zone | 74 | 42 | 30 | 24 |
| | B zone | 74 | 42 | 30 | 24 |
| | C zone | 74 | 42 | 30 | 24 |
| | D zone | 50 | 34 | 26 | 20 |
| | E zone | 50 | 34 | 26 | 20 |
| | F zone | 50 | 34 | 26 | 20 |
| ASUG15LZAS | A zone | 80 | 42 | 28 | 22 |
| | B zone | 80 | 42 | 28 | 22 |
| | C zone | 80 | 42 | 28 | 22 |
| | D zone | 54 | 34 | 24 | 18 |
| | E zone | 54 | 34 | 24 | 18 |
| | F zone | 54 | 34 | 24 | 18 |

1-2. Heating operation

A sensor (room temperature thermistor) built in indoor unit body will usually perceive difference or variation between setting temperature and present room temperature, and controls operation frequency of compressor.

- If the room temperature is 6.0 °C lower than a set temperature, the compressor operation frequency will attain to maximum performance.
- If the room temperature is 1.0 °C higher than a set temperature, the compressor will be stopped.
- When the room temperature is within the range of +1.0°C to -6.0°C of the setting temperature, the compressor frequency is controlled within the range shown below.


- **Compressor frequency range**

Unit: rps

| Model name | Minimum frequency | Maximum frequency |
|--|-------------------|-------------------|
| ASUG09LZAS ASUG12LZAS ASUG15LZAS | 8 | 130 |

- **Limit of maximum speed based on outdoor temperature**

In heating operation, maximum frequency is defined by outdoor temperature and fan mode.



Unit: rps

| Model name | Outdoor temperature zone | Indoor unit fan mode | | | |
|--------------------------|--------------------------|----------------------|-----|-----|-------|
| | | HIGH | MED | LOW | QUIET |
| ASUG09LZAS ASUG12LZAS | A zone | 130 | 130 | 58 | 46 |
| | B zone | 130 | 130 | 58 | 46 |
| | C zone | 130 | 130 | 58 | 46 |
| ASUG15LZAS | A zone | 130 | 130 | 54 | 42 |
| | B zone | 130 | 130 | 54 | 42 |
| | C zone | 130 | 130 | 54 | 42 |

1-3. Dry operation

The compressor rotation frequency shall change according to the temperature, set temperature, and room temperature variation which the room temperature sensor of the indoor unit has detected as shown in the table below.


Zone is defined by set temperature and room temperature.

- **Compressor frequency range**

Unit: rps

| Model name | Outdoor temperature zone | Operating frequency |
|--------------------------|--------------------------|---------------------|
| ASUG09LZAS ASUG12LZAS | X zone | 24 |
| | J zone | 18 |
| | Y zone | 0 |
| ASUG15LZAS | X zone | 22 |
| | J zone | 16 |
| | Y zone | 0 |


- **Compressor control based on room temperature**



1-4. Compressor frequency at normal start-up

■ Models: AOUG09LZAH1, AOUG12LZAH1, and AOUG15LZAH1

Compressor frequency soon after starting is controlled as below.




| Frequency (rps) | I | II | III | IV | V | VI |
|-----------------|----|-----|-----|-----|-----|-----|
| | 35 | 52 | 64 | 71 | 89 | 97 |
| Time (sec) | 1 | 2 | 3 | 4 | 5 | 6 |
| | 60 | 140 | 170 | 200 | 350 | 410 |

1-5. Compressor frequency limitation by outdoor temperature


The minimum compressor frequency is limited by outdoor temperature as below.

- **Cooling/Dry mode**



| Model name | Outdoor temperature zone | Limitation of compressor frequency |
|----------------------------|--------------------------|------------------------------------|
| AOUG09LZAH1 AOUG12LZAH1 | A zone | 37 rps |
| | B zone | 37 rps |
| | C zone | 37 rps |
| | D zone | 28 rps |
| | E zone | 1 rps |
| | F zone | 22 rps |
| AOUG15LZAH1 | A zone | 33 rps |
| | B zone | 33 rps |
| | C zone | 33 rps |
| | D zone | 25 rps |
| | E zone | 10 rps |
| | F zone | 20 rps |

• Heating mode



| Model name | Outdoor temperature zone | Limitation of compressor frequency |
|----------------------------|--------------------------|------------------------------------|
| AOUG09LZAH1 AOUG12LZAH1 | A zone | 34 rps |
| | B zone | 34 rps |
| | C zone | 34 rps |
| | D zone | 15 rps |
| | E zone | 14 rps |
| | F zone | 14 rps |
| AOUG15LZAH1 | A zone | 30 rps |
| | B zone | 30 rps |
| | C zone | 30 rps |
| | D zone | 13 rps |
| | E zone | 10 rps |
| | F zone | 10 rps |

2. Auto changeover operation

When the air conditioner is set to AUTO mode by remote controller, operation starts in the optimum mode from among heating, cooling, dry and monitoring modes. During operation, the optimum mode is automatically switched in accordance with temperature changes. The temperature can be set between 18°C and 30°C in 1.0°C steps.

- When operation starts, indoor fan and outdoor fan are operated for around 1 minute. Room temperature and outdoor temperature are sensed, and the operation mode is selected in accordance with the table below.

| Room temperature | Operation mode |
|---|----------------|
| $T_r > T_s + 2^{\circ}\text{C}$ | Cooling |
| $T_s + 2^{\circ}\text{C} \geq T_r \geq T_s - 2^{\circ}\text{C}$ | Middle zone |
| $T_r < T_s - 2^{\circ}\text{C}$ | Heating |

Tr: Room temperature

Ts: Setting temperature


NOTE: When the operation mode is middle zone, indoor unit operation mode is selected as below.

- Same operation mode is selected as outdoor unit.
If outdoor unit is operating in cooling and heating mode, indoor unit will be operated by the same operation mode.
- Selected by outdoor temperature.
If outdoor unit is operating in other than cooling and heating mode, indoor unit will be operated according to the outdoor temperature as below.

| Outdoor temp. | Operation mode |
|----------------|----------------|
| 25°C or more | Cooling |
| Less than 25°C | Heating |

- When the compressor was stopped for 6 consecutive minutes by temperature control function after the cooling or heating mode was selected as above, operation is switched to monitoring mode and the operation mode selection is done again.
- When the middle zone is selected on the predetermining of the operation mode, the operation mode before the changing to the monitoring mode is selected.

Operation flow chart



CONTROL AND FUNCTIONS

CONTROL AND FUNCTIONS

3. Fan control

Tr: Room temperature

Ts: Setting temperature

3-1. Indoor fan control

■ Fan speed

Indoor fan speed is defined as below.

| Operation mode | Fan mode | Speed (rpm) | |
|----------------|---------------------|----------------------------|----------------------------|
| | | ASUG09LZAS ASUG12LZAS | ASUG15LZAS |
| Heating | POWERFUL | 1,270 | 1,370 |
| | HIGH | 1,200 | 1,300 |
| | MED+ | 1,050 | 1,130 |
| | MED | 950 | 1,050 |
| | LOW | 780 | 780 |
| | QUIET | 590 | 650 |
| | Cool air prevention | 520 | 570 |
| | S-LOW | 520 | 520 |
| Cooling/Fan | POWERFUL | 1,270 | 1,340 |
| | HIGH | 1,200 | 1,270 |
| | MED | 950 | 1,050 |
| | LOW | 780 | 780 |
| | QUIET | 590 | 650 |
| | Soft quiet | 520 ^{*1} | 570 ^{*1} |
| | S-LOW | 520 ^{*2} | 520 ^{*2} |
| Dry | | X zone: 590 J zone: 550 | X zone: 650 J zone: 610 |

*1: Fan mode only

*2: Cooling mode only

■ Fan operation


Airflow can be switched in 5 steps such as AUTO, QUIET, LOW, MED, HIGH while indoor unit fan only runs.

When fan mode is set at AUTO, it operates on MED fan speed.

Cooling operation

Switch the airflow AUTO, and indoor fan motor will run according to room temperature, as below.
On the other hand, if switched in HIGH—QUIET, indoor motor will run at a constant airflow of COOL operation modes QUIET, LOW, MED, HIGH as shown in “Fan speed” above.

Airflow change over (Cooling: Auto)



Dry operation


During dry operation, fan speed setting can not be changed as shown in “Fan speed” above.

Heating operation

Switch the airflow AUTO, and the indoor fan motor will run according to a room temperature, as below.

On the other hand, if switched in HIGH—QUIET, the indoor motor will run at a constant airflow of HEAT operation modes QUIET, LOW, MED, HIGH as shown in “Fan speed” above.


Airflow change over (Heating: Auto)




■ Cool air prevention control (heating mode)

The maximum value of the indoor fan speed is set as shown below, based on the detected temperature by the indoor heat exchanger sensor on heating mode.


- Normal operation




7 minutes later:




- **Powerful operation**



7 minutes later:




- **10 °C HEAT operation**



■ Moisture return prevention control (cooling and dry mode)

Switch the airflow AUTO at cooling mode, and the indoor fan motor will run as shown below.



3-2. Outdoor fan control

■ Outdoor fan motor


This outdoor unit has a DC fan motor. (Control method is different between AC and DC motors.)

■ Fan speed

● Model: AOUG09LZAH1

Fan speed is defined by outdoor temperature and compressor frequency.

• Outside air temperature zone selection



Unit: rpm

| Fan step | Cooling | Heating | Dry | Cooling or dry at low outdoor temp. | | |
|----------|---------|---------|--------|-------------------------------------|--------|--------|
| | Y zone | | Y zone | Z zone | F zone | G zone |
| S-HIGH2 | — | 1,100 | — | — | — | — |
| S-HIGH1 | 1,050 | 1,100 | — | — | — | — |
| HIGH | 1,050 | 1,100 | — | — | — | — |
| 10 | — | 1,100 | — | — | — | — |
| 9 | 1,050 | 1,100 | 1,050 | 850 | 320 | 270 |
| 8 | 870 | 870 | 870 | 850 | 320 | 270 |
| 7 | 760 | 780 | 760 | 770 | 320 | 270 |
| 6 | 760 | 760 | 760 | 630 | 270 | 230 |
| 5 | 560 | 760 | 560 | 440 | 270 | 230 |
| 4 | 440 | 550 | 440 | 320 | 270 | 230 |
| 3 | 440 | 500 | 440 | 320 | 270 | 230 |
| 2 | 440 | 420 | 440 | 320 | 270 | 230 |
| 1 | 440 | 420 | 440 | 320 | 270 | 230 |


NOTE: After defrost control on the heating mode, the fan speed is kept higher regardless of the compressor frequency.

Fan speed after defrost control: 1,100 rpm

● Model: AOUG12LZAH1

Fan speed is defined by outdoor temperature and compressor frequency.

• Outside air temperature zone selection



Unit: rpm

| Fan step | Cooling | Heating | Dry | Cooling or dry at low outdoor temp. | | |
|----------|---------|---------|--------|-------------------------------------|--------|--------|
| | Y zone | | Y zone | Z zone | F zone | G zone |
| S-HIGH2 | — | 1,100 | — | — | — | — |
| S-HIGH1 | 1,050 | 1,100 | — | — | — | — |
| HIGH | 1,050 | 1,100 | — | — | — | — |
| 10 | — | 1,100 | — | — | — | — |
| 9 | 1,050 | 1,100 | 1,050 | 850 | 320 | 270 |
| 8 | 810 | 870 | 810 | 850 | 320 | 270 |
| 7 | 810 | 760 | 810 | 770 | 320 | 270 |
| 6 | 560 | 760 | 560 | 630 | 270 | 230 |
| 5 | 560 | 680 | 560 | 440 | 270 | 230 |
| 4 | 440 | 530 | 440 | 320 | 270 | 230 |
| 3 | 440 | 500 | 440 | 320 | 270 | 230 |
| 2 | 440 | 420 | 440 | 320 | 270 | 230 |
| 1 | 440 | 420 | 440 | 320 | 270 | 230 |


NOTE: After defrost control on the heating mode, the fan speed is kept higher regardless of the compressor frequency.

Fan speed after defrost control: 1,100 rpm

● Model: AOUG15LZAH1

Fan speed is defined by outdoor temperature and compressor frequency.

• Outside air temperature zone selection



Unit: rpm

| Fan step | Cooling | Heating | Dry | Cooling or dry at low outdoor temp. | | |
|----------|---------|---------|--------|-------------------------------------|--------|--------|
| | Y zone | | Y zone | Z zone | F zone | G zone |
| S-HIGH2 | — | 1,100 | — | — | — | — |
| S-HIGH1 | 1,050 | 1,100 | — | — | — | — |
| HIGH | 1,050 | 1,100 | — | — | — | — |
| 10 | — | 1,100 | — | — | — | — |
| 9 | 1,050 | 1,100 | 1,050 | 850 | 320 | 270 |
| 8 | 840 | 920 | 840 | 850 | 320 | 270 |
| 7 | 750 | 920 | 750 | 770 | 320 | 270 |
| 6 | 690 | 710 | 690 | 630 | 270 | 230 |
| 5 | 560 | 620 | 560 | 440 | 270 | 230 |
| 4 | 440 | 560 | 440 | 320 | 270 | 230 |
| 3 | 440 | 500 | 440 | 320 | 270 | 230 |
| 2 | 440 | 440 | 440 | 320 | 270 | 230 |
| 1 | 440 | 440 | 440 | 320 | 270 | 230 |


NOTE: After defrost control on the heating mode, the fan speed is kept higher regardless of the compressor frequency.

Fan speed after defrost control: 1,100 rpm

4. Louver control

4-1. Vertical airflow direction louver control

Each time the button is pressed, the air direction range will change as below:



- Remote controller display is not changed.
- Vertical airflow direction is set automatically as shown, in accordance with the type of operation selected.


Cooling / Dry mode : Horizontal flow 1

Heating mode : Downward flow 6

- During AUTO operation, for the first a few minutes after beginning operation, airflow will be horizontal 1; the air direction cannot be adjusted during this period. The airflow direction setting will temporarily become 1 when the temperature of the airflow is low at the start of the Heating mode.
- After beginning of AUTO/HEAT mode operated and automatic defrosting operation, the airflow will be horizontal 1. However, the airflow direction cannot be adjusted at beginning AUTO operation mode.

4-2. Horizontal airflow direction louver control

Each time the button is pressed, the air direction range will change as below:



Remote controller display is not changed.

4-3. Swing operation

- To select vertical airflow swing operation
When the swing signal is received, the vertical airflow direction louver starts to swing.
 - Swinging range
 - Cooling mode/dry mode/fan mode (1 to 3): 1 ↔ 4
 - Heating mode/fan mode (4 to 6): 3 ↔ 6
 - When the indoor fan is S-LOW or stop mode, the swing operation is interrupted and it stops at either upper end or bottom end.
- To select horizontal airflow swing operation
When the swing signal is received, the horizontal airflow direction louver starts to swing.
 - Swinging range
 - All mode: 1 ↔ 5
 - When the indoor fan is S-LOW or stop mode, the swing operation is interrupted and it stops at either upper end or bottom end.
- To select vertical and horizontal airflow swing operation
When the swing signal is received, both of the vertical and the horizontal airflow direction louver start to swing.


5. Timer operation control

5-1. Wireless remote control


| On/Off timer | Program timer | Sleep timer | Weekly timer |
|--------------|---------------|-------------|--------------|
| ○ | ○ | ○ | ○ |

■ On/Off timer

- Off timer: When the clock reaches the set timer, the air conditioner will be turned off.




- On timer: When the clock reaches the set timer, the air conditioner will be turned on.



■ Program timer

- The program timer allows the off timer and the on timer to be used in combination one time.




- Operation will start from the timer setting (either off timer and on timer) whichever is closest to the clock current timer setting. The order of operations is indicated by the allow in the remote controller screen.
- Sleep timer operation cannot be combined with on timer operation.

■ Sleep timer

If the sleep timer is set, the room temperature is monitored and the operation is stopped automatically. If the operation mode or the set temperature is change after the sleep timer is set, the operation is continued according to the changed setting of the sleep timer from that time on.


- In the cooling operation mode

When the sleep timer is set, the setting temperature is increased 1°C. It increases the setting temperature another 1°C after 1 hour. After that, the setting temperature is not changed and the operation is stopped at the setting time.



- In the heating operation mode

When the sleep timer is set, the setting temperature is decreased 1°C. It decreases the setting temperature another 1°C every 30 minutes. Upon lowering 4°C, the setting temperature is not changed and the operation is stopped at the setting time.



■ Weekly timer


On and off timer can be combined, and up to 4 reservations per day and 28 reservations per week. Before setting the program, set the week and time of the air conditioner at first. If the week and time are not set, the weekly timer will not operate correctly at the setting time.

5-2. Wired remote control


| On/Off timer | Program timer | Sleep timer | Weekly timer | Temperature set back timer |
|--------------|---------------|-------------|--------------|----------------------------|
| ○ | ○ | ○ | ○ | ○ |

■ On/Off timer

- Off timer: When the clock reaches the set timer, the air conditioner will be turned off.




- On timer: When the clock reaches the set timer, the air conditioner will be turned on.



■ Program timer

- The program timer allows the off timer and the on timer to be used in combination one time.




- Operation will start from the timer setting (either off timer and on timer) whichever is closest to the clock current timer setting. The order of operations is indicated by the allow in the remote controller screen.
- Sleep timer operation cannot be combined with on timer operation.

■ Sleep timer

If the sleep timer is set, the room temperature is monitored and the operation is stopped automatically. If the operation mode or the set temperature is change after the sleep timer is set, the operation is continued according to the changed setting of the sleep timer from that time on.


- In the cooling operation mode

When the sleep timer is set, the setting temperature is increased 1°C. It increases the setting temperature another 1°C after 1 hour. After that, the setting temperature is not changed and the operation is stopped at the setting time.



- In the heating operation mode

When the sleep timer is set, the setting temperature is decreased 1°C. It decreases the setting temperature another 1°C every 30 minutes. Upon lowering 4°C, the setting temperature is not changed and the operation is stopped at the setting time.




■ Weekly timer

On and off timer can be combined, and up to 4 reservations per day and 28 reservations per week. Before setting the program, set the week and time of the air conditioner at first. If the week and time are not set, the weekly timer will not operate correctly at the setting time.

■ Temperature set back timer

- The SET BACK timer only changes the set temperature for 7 days, it cannot be used to start or stop air conditioner operation.
- The SET BACK timer can be set to operate up to two times per day but only one temperature setting can be used.
- During COOLING/DRY mode, the air conditioner will operate at a minimum of 18°C even if the SET BACK temperature is set to 17°C or lower.

Case of SET BACK timer on the Cooling operation. (Setting temperature :22°C, SET BACK temperature :26°C)



CONTROL AND FUNCTIONS

CONTROL AND FUNCTIONS

6. Defrost operation control

Tn: Outdoor unit heat exchanger temperature

Ta: Outdoor temperature

Tn10: Temperature at 10 minutes after compressor start

Tnb: Temperature before 5 minutes

• Triggering condition

The defrost operation starts when outdoor unit heat exchanger temperature sensor detects the temperature lower than the values shown below.

– 1st time defrosting after starting operation

| Compressor integrating operation time | Less than 17 min. | 17 to 57 min. | More than 57 min. |
|---------------------------------------|-------------------|--|-------------------------------|
| Condition | Does not operate | $T_n \leq -9^{\circ}\text{C}$ and $T_n - T_a \geq 5$ deg | $T_n \leq -5^{\circ}\text{C}$ |

– 2nd time and after

| Compressor integrating operation time | Less than 40 min. | More than 40 min. |
|---------------------------------------|-------------------|---|
| Condition | Does not operate | $T_n - T_{n10} < -5$ deg ($T_n \leq -6^{\circ}\text{C}$) $T_n - T_{nb} < -2$ deg ($T_n \leq -6^{\circ}\text{C}$) $T_n \leq -20^{\circ}\text{C}$ ($T_a \geq -10^{\circ}\text{C}$) $T_n \leq -7^{\circ}\text{C}$ or $T_n \leq -25^{\circ}\text{C}$ ($T_a < -10^{\circ}\text{C}$) |

– Integrating defrost (Constant monitoring)

| Compressor integrating operation time | More than 240 min. (For long continuous operation) | More than 213 min. (For long continuous operation) | Less than 10 min.* (For intermittent operation) |
|---------------------------------------|--|--|---|
| Condition | $T_n \leq -3^{\circ}\text{C}$ | $T_n \leq -5^{\circ}\text{C}$ | Count of the compressor off: 40 times |

*: If the compressor continuous operation time is less than 10 minutes, the number of the compressor off is counted. If any defrost operated, the compressor off count is cleared.

• Release condition

The defrost operation is released when either one of the conditions below is satisfied.

| | |
|---|--------------|
| Outdoor unit heat exchanger temperature (after 1 minute or later since compressor start) | 13°C or more |
| Compressor operation time | 15 minutes |

6-1. Defrost operation in heating operation stopped

If the outdoor unit is frosted when stopping the heating operation, it stops after performing the automatic defrosting operation.

In this time, if the indoor unit operation lamp flashes slowly (6 sec on/2 sec off), the outdoor unit allow the heat exchanger to defrost, and then stop.

• Triggering condition

When all of the following conditions are satisfied in heating operation

- Compressor operation integrating time: 30 minutes or more
- Compressor continuous operation time: 10 minutes or more
- Outdoor unit heat exchanger temperature: -4°C or less

• Release condition

The defrost operation is released when either one of the conditions below is satisfied.

| | |
|---|--------------|
| Outdoor unit heat exchanger temperature (after 1 minute or later since compressor start) | 13°C or more |
| Compressor operation time | 15 minutes |

7. Various control

7-1. Auto restart

When the power was interrupted by a power failure etc. during operation, the operation contents at that time are memorized and when the power is recovered, operation is automatically started with the memorized operation contents.

| Operation contents memorized when the power is interrupted | |
|---|--|
| Operation mode | |
| Setting temperature | |
| Fan mode setting | |
| Timer mode and set time (set by wireless remote controller) | |
| Airflow direction setting | |
| Swing | |
| ECONOMY operation | |
| 10 °C HEAT operation | |
| Outdoor low noise operation | |
| Remote control setting | |
| WLAN LED setting | |

7-2. MANUAL AUTO operation

When the wireless remote controller is lost or battery power dissipated, this function will work without the remote controller.

When MANUAL AUTO button is pressed more than 3 seconds and less than 10 seconds, MANUAL AUTO operation starts as shown in the table below. To stop operation, press the MANUAL AUTO button for 3 seconds.

| | |
|---|---|
| Operation mode | Auto changeover |
| Fan mode | AUTO |
| Timer mode | Continuous (no timer setting available) |
| Setting temperature | 24°C |
| Vertical airflow direction louver setting | Standard |
| Horizontal airflow direction louver setting | According to memory position |
| SWING | Off |
| ECONOMY | Off |
| Human sensor | Off |

7-3. Forced cooling operation

The outdoor unit may not operate depending on the room temperature.

When FORCED COOLING OPERATION button is pressed more than 10 seconds, forced cooling operation starts as shown in the table below.

| | |
|---|---|
| Operation mode | Cooling |
| Fan mode | HIGH |
| Timer mode | Continuous (no timer setting available) |
| Setting temperature | 24°C |
| Vertical airflow direction louver setting | Standard |
| SWING | Off |
| ECONOMY | Off |
| Human sensor | Off |

- During the forced cooling operation, it operates regardless of room temperature sensor.
- Operation LED and timer LED blink at the same time during the forced cooling operation. They blink for 1 second ON and 1 second OFF on both operation LED and timer LED (same as test operation).

By performing one of the following action, test operation will be canceled:

- Pressing the remote controller START/STOP button
- Pressing FORCED COOLING OPERATION button for 3 seconds
- 60 minutes passed after starting forced cooling operation

NOTE: When HEAT operation is selected on the remote controller during forced cooling operation, heating test run will begin in about 3 minutes.

7-4. 10 °C HEAT operation

10 °C HEAT operation performs as below setting when pressing 10 °C HEAT button.

| | |
|---------------------|-------------------|
| Operation mode | Heating |
| Setting temperature | 10°C |
| Fan mode | AUTO |
| LED display | Economy |
| Defrost operation | Operate as normal |

7-5. ECONOMY operation

The ECONOMY operation starts by pressing ECONOMY button on the remote controller.

The ECONOMY operation is almost the same operation as below settings.

| Mode | Cooling/Dry | Heating |
|--------------------|--------------------------|--------------------------|
| Target temperature | Setting temperature +1°C | Setting temperature -1°C |

7-6. POWERFUL operation

The POWERFUL operation starts by pressing POWERFUL button on the remote controller. The indoor unit and outdoor unit operate at maximum power as shown in the table below.

| | | |
|---|---------|----------|
| Compressor frequency | | Maximum |
| Fan mode | | POWERFUL |
| Vertical airflow direction louver setting | Cooling | 3 |
| | Dry | |
| | Heating | 6 |


Release condition:

- Cooling/Dry
Room temperature \leq Setting temperature -0.5°C or Operation time has passed 20 minutes.
- Heating
Room temperature \geq Setting temperature $+0.5^{\circ}\text{C}$ or Operation time has passed 20 minutes.


7-7. Compressor preheating

By preheating the compressor, warm airflow is quickly discharged when the operation is started.

- **Triggering condition**
 - 30 minutes after compressor stopped.
 - Outdoor unit heat exchanger temperature (T_n)



When the jumper wire (JM2) is disconnected:



7-8. Electronic expansion valve control

The most proper opening of the electronic expansion valve is calculated and controlled under the present operating condition based on the table below.

| Operation mode | Pulse range |
|------------------|---------------------------|
| Cooling/dry mode | Between 52 and 480 pulses |
| Heating mode | |

NOTE: At the time of supplying the power to the outdoor unit, the initialization of the electronic expansion valve is operated (528 pulses are input to the closing direction).

7-9. Prevention to restart for 3 minutes (3 minutes st)

When the compressor fails to start for the number of times below, it does not enter operation status for 3 minutes.

| | |
|------------------|----|
| Retry number | 50 |
| Retry set number | 3 |

When the compressor fails to start in the retry set number above, the compressor is stopped.

7-10. 4-way valve control

- If heating mode is selected at the compressor start, 4-way valve is energized for heating.
- When the air conditioner is switched between cooling and heating mode, compressor is stopped, and the 4-way valve is switched when the 140 seconds passes and the compressor is started.

7-11. Outdoor unit low noise operation

The outdoor unit low noise operation functions by OUTDOOR UNIT LOW NOISE button on the remote controller.

This operation stops the PFC control, and changes the current value.

- **Models: AOUG09LZAH1 and AOUG12LZAH1**

| Operation mode | Current | |
|------------------|-------------------|-------------------|
| | Trigger condition | Release condition |
| Cooling/Dry mode | 4.5 A | 4.0 A |
| Heating mode | 3.0 A | 2.5 A |

- **Model: AOUG15LZAH1**

| Operation mode | Current | |
|------------------|-------------------|-------------------|
| | Trigger condition | Release condition |
| Cooling/Dry mode | 4.5 A | 4.0 A |
| Heating mode | 3.5 A | 3.0 A |

8. Various protections

8-1. Discharge gas temperature over-rise prevention control

The discharge gas temperature sensor (discharge thermistor: outdoor unit side) detects the discharge gas temperature.

- When the discharge temperature becomes higher than the trigger condition, the compressor frequency is decreased as the table below, and it continues to decrease until the discharge temperature becomes lower than the trigger condition.
- When the discharge temperature becomes lower than the release condition, control of compressor frequency is released.
- When the discharge temperature becomes higher than the compressor protection temperature, the compressor is stopped and the indoor unit LED starts blinking.

| | |
|-----------------------------------|---------------------|
| Trigger condition | 104°C |
| Compressor frequency | -20 rps/120 seconds |
| Release condition | 101°C |
| Compressor protection temperature | 110°C |

8-2. Anti-freezing control (cooling and dry mode)

The compressor frequency is decrease in cooling and dry mode when the indoor unit heat exchanger temperature sensor detects the temperature lower than the trigger condition.

When the indoor unit heat exchanger temperature reaches release condition, the anti-freezing control is stopped.

| | | |
|-------------------|------------------------|------|
| Trigger condition | | 4°C |
| Release condition | Outdoor temp. ≥ 10°C*1 | 7°C |
| | Outdoor temp. ≥ 12°C*2 | |
| | Outdoor temp. < 10°C*1 | 13°C |
| | Outdoor temp. < 12°C*2 | |

*1: During the outdoor temperature dropping

*2: During the outdoor temperature rising

8-3. Current release control

The compressor frequency is controlled so that the outdoor unit input current does not exceeds current limit value set according to the outdoor temperature.

The compressor frequency returns according to the operation mode, when the current becomes lower than the release value.

■ Models: AOUG09LZAH1 and AOUG12LZAH1

| Operation mode | Outdoor temp. (Ta) | Trigger condition | Release condition |
|----------------|--|-------------------|-------------------|
| Cooling | $50^{\circ}\text{C} \leq \text{Ta}$ | 4.5 A | 4.0 A |
| | $46^{\circ}\text{C} \leq \text{Ta} < 50^{\circ}\text{C}$ | 4.5 A | 4.0 A |
| | $40^{\circ}\text{C} \leq \text{Ta} < 46^{\circ}\text{C}$ | 6.0 A | 5.5 A |
| | $12^{\circ}\text{C} \leq \text{Ta} < 40^{\circ}\text{C}$ | 8.5 A | 8.0 A |
| | $2^{\circ}\text{C} \leq \text{Ta} < 12^{\circ}\text{C}$ | 8.5 A | 8.0 A |
| | $\text{Ta} < 2^{\circ}\text{C}$ | 8.5 A | 8.0 A |
| Heating | $17^{\circ}\text{C} \leq \text{Ta}$ | 7.0 A | 6.5 A |
| | $12^{\circ}\text{C} \leq \text{Ta} < 17^{\circ}\text{C}$ | 9.0 A | 8.5 A |
| | $5^{\circ}\text{C} \leq \text{Ta} < 12^{\circ}\text{C}$ | 10.0 A | 9.5 A |
| | $\text{Ta} < 5^{\circ}\text{C}$ | 10.0 A | 9.5 A |

■ Model: AOUG15LZAH1

| Operation mode | Outdoor temp. (Ta) | Trigger condition | Release condition |
|----------------|--|-------------------|-------------------|
| Cooling | $50^{\circ}\text{C} \leq \text{Ta}$ | 4.5 A | 4.0 A |
| | $46^{\circ}\text{C} \leq \text{Ta} < 50^{\circ}\text{C}$ | 4.5 A | 4.0 A |
| | $40^{\circ}\text{C} \leq \text{Ta} < 46^{\circ}\text{C}$ | 6.0 A | 5.5 A |
| | $12^{\circ}\text{C} \leq \text{Ta} < 40^{\circ}\text{C}$ | 9.0 A | 8.5 A |
| | $2^{\circ}\text{C} \leq \text{Ta} < 12^{\circ}\text{C}$ | 9.0 A | 8.5 A |
| | $\text{Ta} < 2^{\circ}\text{C}$ | 9.0 A | 8.5 A |
| Heating | $17^{\circ}\text{C} \leq \text{Ta}$ | 7.0 A | 6.5 A |
| | $12^{\circ}\text{C} \leq \text{Ta} < 17^{\circ}\text{C}$ | 9.0 A | 8.5 A |
| | $5^{\circ}\text{C} \leq \text{Ta} < 12^{\circ}\text{C}$ | 11.0 A | 10.5 A |
| | $\text{Ta} < 5^{\circ}\text{C}$ | 12.5 A | 12.0 A |

8-4. Cooling pressure over-rise protection

When the outdoor unit heat exchanger temperature reaches trigger condition below, the compressor is stopped and trouble display is performed.

| | |
|-------------------|------|
| Trigger condition | 65°C |
|-------------------|------|

8-5. Low outdoor temperature protection


When the outdoor temperature sensor detects lower than the trigger condition below, the compressor is stopped.

| Operation mode | Cooling/Dry | Heating |
|-------------------|-------------|---------|
| Trigger condition | -15°C | -20°C |
| Release condition | -10°C | -15°C |

8-6. High temperature and high pressure release control

The compressor is controlled as follows.

■ Models: AOUG09LZAH1, AOUG12LZAH1, and AOUG15LZAH1



| Zone | Operation | |
|--------|--|------------------|
| Zone A | Compressor is stopped. | |
| Zone B | The compressor frequency is decreased. | -25 rps/120 sec. |
| Zone C | | -3 rps/60 sec. |
| Zone D | The protection is released and the operation is returned to normal mode. | |
| Zone E | | |

5. FILED WORKING

CONTENTS

5. FILED WORKING

| | |
|---|--------------|
| 1. Function settings | 05-1 |
| 1-1. Function settings by using remote controller | 05-1 |
| 1-2. Custom code setting for wireless remote controller | 05-9 |
| 1-3. Switching the temperature unit of remote controller..... | 05-10 |
| 2. External input and output..... | 05-11 |
| 2-1. External input..... | 05-12 |
| 2-2. External output | 05-13 |
| 2-3. Combination of external input and output | 05-14 |
| 2-4. Details of function | 05-15 |

1. Function settings

To adjust the functions of this product according to the installation environment, various types of function settings are available.

NOTE: Incorrect settings can cause a product malfunction.

1-1. Function settings by using remote controller

Some function settings can be changed on the remote controller. After confirming the setting procedure and the content of each function setting, select appropriate functions for your installation environment.

■ Setting procedure by using wireless remote controller

The function number and the associated setting value are displayed on the LCD of the remote controller. Follow the instructions written in the local setup procedure supplied with the remote controller, and select appropriate setting according to the installation environment.

Before connecting the power supply of the indoor unit, reconfirm following items:

- Cover for the electrical enclosure on the outdoor unit is in place.
- There is no wiring mistake.
- Piping air tight test and vacuuming have been performed firmly.
- All the necessary wiring work for outdoor unit has been finished.

After reconfirming the items listed above, connect the power supply of the indoor unit.

NOTES:

- Settings will not be changed if invalid numbers or setting values are selected.
- When optional wired remote controller is used, refer to the installation manual enclosed with the remote controller.

Entering function setting mode:

While pressing the POWERFUL button and TEMP. (△) button simultaneously, press the RESET button to enter the function setting mode.

Selecting the function number and setting value:

1. Press the MIN. HEAT button. TEMP. (△) (▽) buttons to select the function number. Press the MIN. HEAT button to switch between the left and right digits.
2. Press the POWERFUL button to proceed to value setting. To return the function number selection, press the POWERFUL button again.
3. Press the TEMP. (△) (▽) buttons to select the setting value. To switch between the left and right digits, press the MIN. HEAT button.
4. Press the MODE button once. Confirm that you hear the beep sound.
5. Press the START/STOP button to fix the function setting. Confirm that you hear the beep sound.
6. Press the RESET button to end the function setting mode.
7. After completing the function setting, be sure to disconnect the power supply and then reconnect it.

Function number
Setting value



⚠ CAUTION

After disconnecting the power supply, wait 30 seconds or more before reconnecting it. The function setting will not become active unless the power supply is disconnected and then reconnected.

NOTES:

- The air conditioner custom code is set to \overline{H} prior to shipment.
- If you do not know the air conditioner custom code setting, try each of the custom codes ($\overline{H} \rightarrow \overline{b}$
 $\rightarrow \overline{c} \rightarrow \overline{d}$) until you find the code that operates the air conditioner.

■ Contents of function setting

Each function setting listed in this section is adjustable in accordance with the installation environment.

NOTE: Setting will not be changed if invalid numbers or setting values are selected.

● Function setting list

| | Function no. | Functions |
|-----|--------------|---|
| 1) | 00 | Remote controller address setting |
| 2) | 11 | Filter sign |
| 3) | 30/31 | Room temperature control for indoor unit sensor |
| 4) | 35/36 | Room temperature control for wired remote controller sensor |
| 5) | 40 | Auto restart |
| 6) | 42 | Room temperature sensor switching |
| 7) | 44 | Remote controller custom code |
| 8) | 46 | External input control |
| 9) | 48 | Room temperature sensor switching (Aux.) |
| 10) | 49 | Indoor unit fan control for energy saving for cooling |
| 11) | 61 | Control switching of external heaters |
| 12) | 62 | Operating temperature switching of external heaters |
| 13) | 66 | Outdoor temperature zone boundary temperature A |
| 14) | 67 | Outdoor temperature zone boundary temperature B |
| 15) | 95 | Heat insulation condition (building insulation) |

1) Remote controller address setting

NOTE: Because this setting is normally done automatically when 2-wire-type wired remote controller is installed, setting is unnecessary.

Multiple indoor units can be operated by using one wired remote controller.

Set the unit number of each indoor unit.

| Function number | Setting value | Setting description | Factory setting |
|-----------------|---------------|---------------------|-----------------|
| 00 | 00 | Unit no. 0 | ◆ |
| | 01 | Unit no. 1 | |
| | 02 | Unit no. 2 | |
| | 03 | Unit no. 3 | |
| | 04 | Unit no. 4 | |
| | 05 | Unit no. 5 | |
| | 06 | Unit no. 6 | |
| | 07 | Unit no. 7 | |
| | 08 | Unit no. 8 | |
| | 09 | Unit no. 9 | |
| | 10 | Unit no. 10 | |
| | 11 | Unit no. 11 | |
| | 12 | Unit no. 12 | |
| | 13 | Unit no. 13 | |
| | 14 | Unit no. 14 | |
| | 15 | Unit no. 15 | |

NOTE: When different type of indoor units (such as wall mounted type and cassette type, cassette type and duct type, or other combinations) are connected using group control system, some functions may no longer be available.

2) Filter sign

Select appropriate intervals for displaying the filter sign on the indoor unit according to the estimated amount of dust in the air of the room.

If the indication is not required, select "No indication" (03).

| Function number | Setting value | Setting description | Factory setting |
|-----------------|---------------|-----------------------------|-----------------|
| 11 | 00 | Standard (400 hours) | |
| | 01 | Long interval (1,000 hours) | |
| | 02 | Short interval (200 hours) | |
| | 03 | No indication | ◆ |

3) Room temperature control for indoor unit sensor

NOTE: Before performing this setting, refer to Function 95.

Depending on the installed environment, correction of the room temperature sensor may be required. Select the appropriate control setting according to the installed environment.

The temperature of the room temperature sensor is corrected as follows:

Corrected temp. = Temp. of the room temp. sensor - Correction temp. value

Example of correction:

When the temperature of the room temp. sensor is 78°F and the setting value is "03" (-2°F), the corrected temp. will be 80°F (78°F - [-2°F]).

The temperature correction values show the difference from the Standard setting "00" (manufacturer's recommended value).

*When Function 95-01 (High insulation) is set, the Standard setting "00" will be the same as "No correction 0.0 °F (0.0 °C)" (01).

| Function number | | Setting value | Setting description | Factory setting |
|---------------------|---------------------|---------------|-------------------------------|------------------------------|
| 30 (For cooling) | 31 (For heating) | 00 | Standard setting* | ◆ |
| | | 01 | No correction 0.0 °F (0.0 °C) | |
| | | 02 | -1 °F (-0.5 °C) | More cooling Less heating |
| | | 03 | -2 °F (-1.0 °C) | |
| | | 04 | -3 °F (-1.5 °C) | |
| | | 05 | -4 °F (-2.0 °C) | |
| | | 06 | -5 °F (-2.5 °C) | |
| | | 07 | -6 °F (-3.0 °C) | |
| | | 08 | -7 °F (-3.5 °C) | |
| | | 09 | -8 °F (-4.0 °C) | |
| | | 10 | +1 °F (+0.5 °C) | Less cooling More heating |
| | | 11 | +2 °F (+1.0 °C) | |
| | | 12 | +3 °F (+1.5 °C) | |
| | | 13 | +4 °F (+2.0 °C) | |
| | | 14 | +5 °F (+2.5 °C) | |
| | | 15 | +6 °F (+3.0 °C) | |
| | | 16 | +7 °F (+3.5 °C) | |
| | | 17 | +8 °F (+4.0 °C) | |

4) Room temperature control for wired remote controller sensor

NOTE: Before performing this setting, refer to Function 95.

Depending on the installed environment, correction of the wire remote temperature sensor may be required. Select the appropriate control setting according to the installed environment.

To change this setting, set Function 42 to Both "01".

Ensure that the Thermo Sensor icon is displayed on the remote controller screen.

*When Function 95-01 (High insulation) is set, the Standard setting "00" will be the same as "No correction 0.0 °C" (01).

| Function number | | Setting value | Setting description | Factory setting |
|---------------------|---------------------|---------------|-------------------------------|------------------------------|
| 35 (For cooling) | 36 (For heating) | 00 | Standard setting* | ◆ |
| | | 01 | No correction 0.0 °F (0.0 °C) | |
| | | 02 | -1 °F (-0.5 °C) | More cooling Less heating |
| | | 03 | -2 °F (-1.0 °C) | |
| | | 04 | -3 °F (-1.5 °C) | |
| | | 05 | -4 °F (-2.0 °C) | |
| | | 06 | -5 °F (-2.5 °C) | |
| | | 07 | -6 °F (-3.0 °C) | |
| | | 08 | -7 °F (-3.5 °C) | |
| | | 09 | -8 °F (-4.0 °C) | |
| | | 10 | +1 °F (+0.5 °C) | Less cooling More heating |
| | | 11 | +2 °F (+1.0 °C) | |
| | | 12 | +3 °F (+1.5 °C) | |
| | | 13 | +4 °F (+2.0 °C) | |
| | | 14 | +5 °F (+2.5 °C) | |
| | | 15 | +6 °F (+3.0 °C) | |
| | | 16 | +7 °F (+3.5 °C) | |
| | | 17 | +8 °F (+4.0 °C) | |

5) Auto restart

Enables or disables automatic restart after a power interruption.

| Function number | Setting value | Setting description | Factory setting |
|-----------------|---------------|---------------------|-----------------|
| 40 | 00 | Enable | ◆ |
| | 01 | Disable | |

NOTE: Auto restart is an emergency function such as for power outage etc. Do not attempt to use this function in normal operation. Be sure to operate the unit by remote controller or external device.

6) Room temperature sensor switching

(Only for wired remote controller)

When using the wired remote controller temperature sensor, change the setting to "Both" (01).

| Function number | Setting value | Setting description | Factory setting |
|-----------------|---------------|---------------------|-----------------|
| 42 | 00 | Indoor unit | ◆ |
| | 01 | Both | |

00: Sensor on the indoor unit is active.

01: Sensors on both indoor unit and wired remote controller are active.

NOTE: Remote controller sensor must be turned on by using the remote controller.

7) Remote controller custom code

(Only for wireless remote controller)

The indoor unit custom code can be changed. Select the appropriate custom code.

| Function number | Setting value | Setting description | Factory setting |
|-----------------|---------------|---------------------|-----------------|
| 44 | 00 | A | ◆ |
| | 01 | B | |
| | 02 | C | |
| | 03 | D | |

8) External input control

"Operation/Stop" mode or "Forced stop" mode can be selected.

| Function number | Setting value | Setting description | Factory setting |
|-----------------|---------------|---------------------------------------|-----------------|
| 46 | 00 | Operation/Stop mode 1 (R.C. enabled) | ◆ |
| | 01 | (Setting prohibited) | |
| | 02 | Forced stop mode | |
| | 03 | Operation/Stop mode 2 (R.C. disabled) | |

9) Room temperature sensor switching (Aux.)

To use the temperature sensor on the wired remote controller only, change the setting to "Wired remote controller" (01).

This function will only work if the function setting 42 is set at "Both" (01).

When the setting value is set to "Both" (00), more suitable control of the room temperature is possible by setting function setting 30 and 31 too.

| Function number | Setting value | Setting description | Factory setting |
|-----------------|---------------|-------------------------|-----------------|
| 48 | 00 | Both | ◆ |
| | 01 | Wired remote controller | |

10) Indoor unit fan control for energy saving for cooling

Enables or disables the power-saving function by controlling the indoor unit fan rotation when the outdoor unit is stopped during cooling operation.

| Function number | Setting value | Setting description | Factory setting |
|-----------------|---------------|---------------------|-----------------|
| 49 | 00 | Disable | |
| | 01 | Enable | |
| | 02 | Remote controller | ◆ |

00: When the outdoor unit is stopped, the indoor unit fan operates continuously following the setting on the remote controller.

01: When the outdoor unit is stopped, the indoor unit fan operates intermittently at a very low speed.

02: Enable or disable this function by remote controller setting.

NOTES:

- As the factory setting, this setting is initially invalidated.
- Set to "00" or "01" when connecting a remote controller that cannot set the Fan control for energy saving function or connecting a network converter.
To confirm if the remote controller has this setting, refer to the operating manual of each remote controller.

11) Control switching of external heaters

Sets the control method for external heater to be used.

For details, refer to "External heater output" on page 05-20.

| Function number | Setting value | Setting description | Factory setting |
|-----------------|---------------|---|-----------------|
| 61 | 00 | Auxiliary heater control 1 | ◆ |
| | 01 | Auxiliary heater control 2 | |
| | 02 | Heat pump prohibition control | |
| | 03 | Auxiliary heater control by outdoor temperature 1 | |
| | 04 | Auxiliary heater control by outdoor temperature 2 | |

12) Operating temperature switching of external heaters

Sets the temperature conditions when the external heater is ON.

For details, refer to "External heater output" on page 05-20.

| Function number | Setting value | Setting description | | Factory setting |
|-----------------|---------------|---------------------|-----------------|-----------------|
| | | Heater: On | Heater: Off | |
| 62 | 00 | -5.4 °F (-3 °C) | -1.8 °F (-1 °C) | ◆ |
| | 01 | -3.6 °F (-2 °C) | -1.8 °F (-1 °C) | |
| | 02 | -3.6 °F (-2 °C) | -1.8 °F (-1 °C) | |
| | 03 | -5.4 °F (-3 °C) | -1.8 °F (-1 °C) | |
| | 04 | -7.2 °F (-4 °C) | -1.8 °F (-1 °C) | |
| | 05 | -9.0 °F (-5 °C) | -1.8 °F (-1 °C) | |

13) Outdoor temperature zone boundary temperature A

Setting required if changing of the outdoor temperature setting for heat pump prohibition zone is required when auxiliary heater control by outdoor temperature 1 and 2 are performed on the indoor unit. For details, refer to "External heater output" on page 05-20.

| Function number | Setting value | Setting description | Factory setting |
|-----------------|---------------|---------------------|-----------------|
| 66 | 00 | -4.0 °F (-20 °C) | ◆ |
| | 01 | -0.4 °F (-18 °C) | |
| | 02 | 3.2 °F (-16 °C) | |
| | 03 | 6.8 °F (-14 °C) | |
| | 04 | 10.4 °F (-12 °C) | |
| | 05 | 14.0 °F (-10 °C) | |
| | 06 | 17.6 °F (-8 °C) | |
| | 07 | 21.2 °F (-6 °C) | |
| | 08 | 24.8 °F (-4 °C) | |

14) Outdoor temperature zone boundary temperature B

Setting required if changing of the outdoor temperature setting for heat pump only zone is required when auxiliary heater control by outdoor temperature 1 is performed on the indoor unit. For details, refer to "External heater output" on page 05-20.

| Function number | Setting value | Setting description | Factory setting |
|-----------------|---------------|---------------------|-----------------|
| 67 | 00 | 42.8 °F (6 °C) | ◆ |
| | 01 | 14.0 °F (-10 °C) | |
| | 02 | 17.6 °F (-8 °C) | |
| | 03 | 21.2 °F (-6 °C) | |
| | 04 | 24.8 °F (-4 °C) | |
| | 05 | 28.4 °F (-2 °C) | |
| | 06 | 32.0 °F (0 °C) | |
| | 07 | 35.6 °F (2 °C) | |
| | 08 | 39.2 °F (4 °C) | |
| | 09 | 42.8 °F (6 °C) | |
| | 10 | 46.4 °F (8 °C) | |
| | 11 | 50.0 °F (10 °C) | |
| | 12 | 53.6 °F (12 °C) | |
| | 13 | 57.2 °F (14 °C) | |
| | 14 | 60.8 °F (16 °C) | |
| | 15 | 64.4 °F (18 °C) | |

15) Heat insulation condition (building insulation)

Heat insulation conditions differ according to the installed environment.

"Standard insulation" (00) allows system to rapidly respond to the cooling or heating load changes.

"High insulation" (01) is when the heat insulation structure of the building is high and does not require system to rapidly respond to cooling or heating load changes.

When "High insulation" (01) is selected:

- Overheating (overcooling) is prevented at the start-up.
- All room-temperature control settings (Function 30, 31, 35, and 36) will reset to "No correction 0.0 °F (0.0 °C)".

| Function number | Setting value | Setting description | Factory setting |
|-----------------|---------------|---------------------|-----------------|
| 95 | 00 | Standard insulation | ◆ |
| | 01 | High insulation | |

NOTE: When changing Function 95, perform this setting before other room-temperature control settings (Function 30, 31, 35, and 36). If Function 95 is not set first, room-temperature control settings (Function 30, 31, 35, and 36) will be reset and you must re-do them again.

1-2. Custom code setting for wireless remote controller

To interconnect the air conditioner and the wireless remote controller, assignment of the custom code for the wireless remote controller is required.

NOTE: Air conditioner cannot receive a signal if the air conditioner has not been set for the custom code.

When 2 or more air conditioners are installed in a room, and the remote controller is operating an air conditioner other than the one you wish to set, change the custom code of the remote controller to operate only the air conditioner you wish to set. (4 selections possible.)

Confirm the setting of the remote controller custom code and the function setting. If these do not match, the remote controller cannot be used to operate for the air conditioner.

1. Press the START/STOP button until only the clock is displayed on the remote controller display.
2. Press the MODE button for at least 5 seconds to display the current custom code. (Initially set to \overline{A} .)
3. Press the TEMP. (\wedge) (\vee) buttons to change the custom code between $\overline{A} \rightarrow \overline{b} \rightarrow \overline{c} \rightarrow \overline{d}$. Match the code on the display to the air conditioner custom code. (Initially set to \overline{A} .)
4. Press the MODE button again to return to the clock display. The custom code will be changed.



NOTES:


- If no button is pressed within 30 seconds after the custom code is displayed, the system returns to the original clock indicator. In this case, start again from step 1.
- The air conditioner custom code is set to \overline{A} prior to shipment. To change the custom code, contact your retailer.
- If you do not know the assigned code for the air conditioner, try each of the custom code ($\overline{A} \rightarrow \overline{b} \rightarrow \overline{c} \rightarrow \overline{d}$) until you find the code which operates the air conditioner.

1-3. Switching the temperature unit of remote controller


Displayed temperature unit on the remote controller LCD can be switched between °F (Fahrenheit) and °C (Celsius).

To change temperature unit, do as follows:

1. Press the TEMP. (Up) button (∧) for at least 5 seconds to display the current temperature unit. (Factory setting: °F)
2. Press the TEMP. (∧) (∨) buttons to switch the temperature unit between °F and °C.
3. With either of pressing the START/STOP button or no additional button operation for 30 seconds in step 2., the temperature unit currently selected will be set.



2. External input and output



| PCB | External input | External output | Connector | Input select | Input signal |
|---|-----------------------|-------------------------------------|-----------------|-------------------------------|--------------|
| External input and output (UTY-XCSXZ2) | Operation/Stop | — | CN313/ CN314 | Dry contact/ Apply voltage | Edge/Pulse |
| | Forced stop | | CN313 | | Edge |
| | Forced thermostat off | | | | |
| | — | Operation status | CN310 | — | — |
| | | Error status | CN311 | | |
| | | Indoor unit fan operation status | CN312 | | |
| | | External heater output | | | |

NOTE: External input and output PCB cannot be used with Wireless LAN adapter simultaneously.

FIELD WORKING

FIELD WORKING

2-1. External input

With using external input function, some functions on this product can be controlled from an external device.

- "Operation/Stop" mode or "Forced stop" mode can be selected with function setting of indoor unit.
- A twisted pair cable (22AWG) should be used. Maximum length of cable is 492 ft (150 m).
- The wire connection should be separate from the power cable line.

External input and output PCB


The indoor unit Operation/Stop can be set by using the input connector on the PCB.

Input select:

Use either one of these types of connectors according to the application. (Both types of connectors cannot be used simultaneously.)

– Dry contact


In case of internal power supply, set the slide switch of SW301 to "NON VOL" side.



*1: The switches can be used on the following condition: DC 12 V to 24 V, 1 mA to 15 mA.

– Apply voltage

In case of external power supply, set the slide switch of SW301 to "VOL" side.



*1: The switches can be used on the following condition: DC 12 V to 24 V, 1 mA to 15 mA.


*2: Make the power supply DC 12 to 24 V, 10 mA or more.

2-2. External output


Use an external output cable with appropriate external dimension, depending on the number of cables to be installed.

External input and output PCB

- A twisted pair cable (22AWG) should be used. Maximum length of cable is 82 ft (25 m).
- Output voltage: High DC 12 V \pm 2 V, Low 0 V.
- Permissible current: 50 mA
- For details, refer to ["Combination of external input and output"](#) on page 05-14.
- **When indicator or other components are connected directly:**
Example: Rotary SW on External input and output PCB is set to "1".



- **When connecting with a device equipped with a power supply:**
Example: Rotary SW on External input and output PCB is set to "1".



2-3. Combination of external input and output

By combining the function setting of the rotary switch setting of the External input and output PCB, you can select various combinations of functions.

Combination examples of external input and output are as follows:

| External input and output PCB (Rotary SW) | External input | | |
|--|-------------------------------|---------------|-------------|
| | External input and output PCB | | |
| | CN313 | CN314 | Signal type |
| 1 | Operation/Stop | Not available | Edge |
| | Operation | Stop | Pulse |
| 2 | Forced Thermostat OFF | Not available | Edge |
| 3 - 9, A | (Setting prohibited) | | |
| B | Forced Thermostat OFF | Not available | Edge |
| C | Forced Thermostat OFF | Not available | Edge |
| D | Forced Thermostat OFF | Not available | Edge |

| External input and output PCB (Rotary SW) | External output | | |
|--|-------------------------------|----------------------------------|----------------------------------|
| | External input and output PCB | | |
| | CN310 | CN311 | CN312 |
| 1 | Operation/Stop | Error status | Indoor unit fan operation status |
| 2 | Error status | Indoor unit fan operation status | External heater output |
| 3 - 9, A | (Setting prohibited) | | |
| B | Operation/Stop | Indoor unit fan operation status | External heater output |
| C | Operation/Stop | Error status | External heater output |
| D | Operation/Stop | Indoor unit fan operation status | Error status |

NOTE: Input of Operation/Stop depends on the setting of function setting 46.

00: Operation/Stop mode 1 (R.C. enabled)

01: (Setting prohibited)

02: Forced stop


03: Operation/Stop mode 2 (R.C. disabled)

Input signal type

External input and output PCB:

The input signal type can be selected.

Signal type (edge or pulse) can be switched by the DIP switch SW302 on the External input and output PCB.




2-4. Details of function

■ Control input function


- When function setting is “Operation/Stop” mode 1
 - In the case of “Edge” input:

| Function setting | Rotary SW on External input and output PCB | External input | | Input signal | Command |
|------------------|--|-------------------------------|-------|--------------|-----------|
| 46-00 | 1 | External input and output PCB | CN313 | Off → On | Operation |
| | | | | On → Off | Stop |



- In the case of “Pulse” input:

| Function setting | Rotary SW on External input and output PCB | External input | | Input signal | Command |
|------------------|--|-------------------------------|-------|--------------|-----------|
| 46-00 | 1 | External input and output PCB | CN313 | Pulse | Operation |
| | | | CN314 | Pulse | Stop |




NOTES:

- The last command has priority.
- The indoor units within the same remote controller group operates in the same mode.

• When function setting is “Forced stop” mode


– In the case of “Edge” input:

| Function setting | Rotary SW on External input and output PCB | External input | | Input signal | Command |
|------------------|--|-------------------------------|-------|--------------|-------------|
| 46-02 | 1 | External input and output PCB | CN313 | Off → On | Forced stop |
| | | | | On → Off | Normal |



– In the case of “Pulse” input:

| Function setting | Rotary SW on External input and output PCB | External input | | Input signal | Command |
|------------------|--|-------------------------------|-------|--------------|-------------|
| 46-02 | 1 | External input and output PCB | CN313 | Pulse | Forced stop |
| | | | CN314 | Pulse | Normal |




NOTES:

- When the forced stop is triggered, indoor unit stops and Operation/Stop operation by the remote controller is restricted.
- When forced stop function is used with forming a remote controller group, connect the same equipment to each indoor unit within the group.

- When function setting is “Operation/Stop” mode 2


- In the case of “Edge” input:

| Function setting | Rotary SW on External input and output PCB | External input | | Input signal | Command |
|------------------|--|-------------------------------|-------|--------------|----------------------|
| 46-03 | 1 | External input and output PCB | CN313 | Off → On | Operation |
| | | | | On → Off | Stop (R.C. disabled) |



- In the case of “Pulse” input:


| Function setting | Rotary SW on External input and output PCB | External input | | Input signal | Command |
|------------------|--|-------------------------------|-------|--------------|----------------------|
| 46-03 | 1 | External input and output PCB | CN313 | Pulse | Operation |
| | | | CN314 | Pulse | Stop (R.C. disabled) |



NOTE: When “Operation/Stop” mode 2 function is used with forming a remote controller group, connect the same equipment to each indoor unit within the group.

• Forced thermostat off function

| Rotary SW on External input and output PCB | External input | | Input signal | Command |
|--|-------------------------------|-------|--------------|------------------|
| 2 B C | External input and output PCB | CN313 | Off → On | Thermostat off |
| | | | On → Off | Normal operation |



FIELD
WORKING


FIELD
WORKING

■ Control output function

• Operation/Stop status

| Rotary SW on External input and output PCB | External output | | Output signal | Command |
|--|-------------------------------|-------|---------------|-----------|
| 1 | External input and output PCB | CN310 | Off → On | Operation |
| B | | | On → Off | Stop |
| C | | | | |
| D | | | | |


The output is low when the unit is stopped.



• Error status

| Rotary SW on External input and output PCB | External output | | Output signal | Command |
|--|-------------------------------|-------|---------------|---------|
| 1 | External input and output PCB | CN311 | Off → On | Error |
| C | | | On → Off | Normal |
| D | | CN312 | Off → On | Error |
| | | | On → Off | Normal |


The output is ON when an error is generated for the indoor unit.



• Indoor unit fan operation status

| Rotary SW on External input and output PCB | External output | | Output signal | Command |
|--|-------------------------------|-------|---------------|----------|
| 1 | External input and output PCB | CN312 | Off → On | Fan run |
| | | | On → Off | Fan stop |
| 2 | | CN311 | Off → On | Fan run |
| B | | | On → Off | Fan stop |
| D | | | | |

| Output signal | Condition |
|-------------------|--|
| On Low → High | The indoor unit fan is operating. |
| Off High → Low | The fan is stopped or during cold air prevention. During thermostat off when in dry mode operation. |



- External heater output

| Rotary SW on External input and output PCB | External output | | Output signal | Command |
|--|-------------------------------|-------|---------------|------------|
| 2 B C | External input and output PCB | CN312 | Off → On | Heater on |
| | | | On → Off | Heater off |

■ External heater output


| Control | Primary heater | Auxiliary heater | Function setting | |
|---|-----------------|-------------------|---|---------------------|
| | | | Indoor unit | Wired R. C. |
| | | | Control switching external heaters No. 61 | Sensor activation*2 |
| Auxiliary heater control 1 | Heat pump | External device*1 | 61-00 | — |
| Auxiliary heater control 2 | Heat pump | External device | 61-01 | — |
| Heat pump prohibition control | External device | None | 61-02 | On (Enabled) |
| Auxiliary heater control by outdoor temperature 1 | Heat pump | External device | 61-03 | On (Enabled) |
| Auxiliary heater control by outdoor temperature 2 | Heat Pump | External device | 61-04 | On (Enabled) |

NOTES:

- After turning off the heater, 3 minutes of standby time is required by next power-on of the heater.
- For items marked “—” in the table, any of validate or invalidate of the setting are acceptable.
- *1: External device means Hot water, Electrical heater, etc.
- *2: Sensor activation:
 - Setting change from the factory setting is required.
 - Indoor unit fan setting will be on for safety reason without sensor activation of wired remote controller.

● Installation configuration of individual connection

External heating device is installed individually. (No use of indoor unit fan)




⚠ WARNING

- Design and install external heater appropriately with considering its protection.
- Inappropriate designing and installation of external heater may cause a fire by emitted heat from the external heater.
- Fujitsu General Ltd. is not responsible for inappropriate designing or installation of external heating device.

● Auxiliary heater control 1

| Operation | Condition |
|------------|--|
| Heater on | Heater is on as shown in following diagram of heating temperature. |
| Heater off | <ul style="list-style-type: none"> Heater is off as shown in following diagram of heating temperature. Other than heating mode Error occurred Forced thermostat off Fan stop protection |

- Temperature of heater on (Thon): Adjustable by function number 62 (Operating temperature switching of external heaters).
- All control temperatures will shift by adjusting "Thon".



Tr: Room temperature
Ts: Set temperature
Thon: Heater on temperature


Example: When set temperature (Ts) is 72°F (22°C) (Factory setting),

- and room temperature (Tr) increases above 53.6°F (12°C), signal output is on.
- and room temperature (Tr) increases above 69.8°F (21°C), signal output is off.
- and room temperature (Tr) decreases below 66.2°F (19°C), signal output is on.
- and room temperature (Tr) decreases below 50°F (10°C), signal output is off.

● Auxiliary heater control 2

| Operation | Condition |
|------------|--|
| Heater on | Heater is on as shown in following diagram of heating temperature. |
| Heater off | <ul style="list-style-type: none"> Heater is off as shown in following diagram of heating temperature. Other than heating mode Error occurred Forced thermostat off Fan stop protection |

- Temperature of heater on (Thon): Adjustable by function number 62 (Operating temperature switching of external heaters).
- All control temperatures will shift by adjusting "Thon".




Tr: Room temperature
Ts: Set temperature
Thon: Heater on temperature

● Heat pump prohibition control


Perform heating by external heater only. Indoor unit is continuous thermostat off.

| Operation | Condition |
|------------|---|
| Heater on | Heater is on as shown in following diagram of heating temperature. |
| Heater off | <ul style="list-style-type: none"> Heater is off as shown in following diagram of heating temperature. Other than heating mode Error occurred Forced thermostat off |

- Temperature of heater on (Thon): Adjustable by function number 62 (Operating temperature switching of external heaters).
- All control temperatures will shift by adjusting "Thon".



• Operation status



NOTE: In following operations, compressor will be on.

- Other than heating
- Test run


● Auxiliary heater control by outdoor temperature 1

This control selects heat pump or external heater according to the outdoor temperature. When outdoor temperature is high, the heating is performed by using heat pump only.


| Operation | Condition |
|------------|--|
| Heater on | Heater is on as shown in following diagram of heating temperature. |
| Heater off | <ul style="list-style-type: none"> Heater is off as shown in following diagram of heating temperature. Other than heating mode Error occurred Forced thermostat off Heat pump only zone |

- Temperature of heater on (Thon): Adjustable by function number 62 (Operating temperature switching of external heaters).
- All control temperatures will shift by adjusting "Thon".
- Outdoor temperature zone boundary A and B: Adjustable individually by function setting number 66 and 67.

• External heater output




• Outdoor temperature zone



*: Adjustable by function setting 66 and 67

- **Operation status**



* The outdoor temperature zone transition from one to another will stay in that zone for minimum of 30 min.

NOTE: In following operations, compressor will be on in heat pump prohibition zone.

- Other than heating
- Test run


● Auxiliary heater control by outdoor temperature 2

This control selects heat pump or external heater according to the outdoor temperature. Even when outdoor temperature is high, the heating is performed by using both of heat pump and external heater.

| Operation | Condition |
|------------|---|
| Heater on | Heater is on as shown in following diagram of heating temperature. |
| Heater off | <ul style="list-style-type: none"> Heater is off as shown in following diagram of heating temperature. Other than heating mode Error occurred Forced thermostat off |


- Temperature of heater on (Thon): Adjustable by function number 62 (Operating temperature switching of external heaters).
- All control temperatures will shift by adjusting “Thon”.
- Outdoor temperature zone boundary A: Adjustable by function setting number 66.

• External heater output




Tr: Room temperature
Ts: Set temperature
Thon: Heater on temperature

• Outdoor temperature zone



*: Adjustable by function setting 66

- Operation status



* The outdoor temperature zone transition from one to another will stay in that zone for minimum of 30 min.

NOTE: In following operations, compressor will be on in heat pump prohibition zone.

- Other than heating
- Test run