

## **Submittal Data Sheet**

Decoration Panel, Sensing Flow BYCQ125B-W1

## **DESCRIPTION**


The decoration panel attaches to the bottom of the cassette body and is the visible component of the FXFQ series round flow cassette. The infrared occupancy sensor and surface temperature sensor are built into the decoration panel to maintain comfortable temperature distribution in the room.




SPECIFICATIONS	
Model No.:	BYCQ125B-W1
Components Included:	Decoration panel (including mounting screws, wiring harness, long life filter, thermal insulation, antisweat material and infrared floor and presence sensor) and installation manual
Unit Compatibility:	FXFQ07TVJU, FXFQ09TVJU, FXFQ12TVJU, FXFQ15TVJU, FXFQ18TVJU, FXFQ24TVJU, FXFQ30TVJU, FXFQ36TVJU, FXFQ48TVJU
Unit Weight:	12.2 lbs (5.5 kgs.)
Dimensions (W x H x D):	37-3/8" x 2" x 37-3/8" (950 mm x 50 mm x 950 mm)
Material / Finish:	Plastic / Fresh white (6.5Y 9.5/0.5)
Airflow Configurations:	4-way and 3-way
Filter:	Washable filter included as standard; KAFP551K160 (Quantity 1)
Remote Sensor Kit:	Included as standard; KRCS01-4B

## Notes:

## **DIMENSIONAL DRAWINGS**





Daikin North America LLC, 5151 San Felipe, Suite 500, Houston TX, 77056 <u>www.daikinac.com</u> <u>www.daikincomfort.com</u>

When installing infrared and presence sensor, ensure the correct field settings are applied for temperature settings.