


All installations and services must be performed by qualified service personnel.

4. This furnace is ETL listed for closet, alcove or freestanding applications. All applications must comply with the requirements of this manual.

**Combustible Floor Base
Model: 70-BASE**

Figure 1A.



**Cottage Base
Model: 01COT-BASE**




Figure 1B.

D. BASE INSTALLATION

1. Combustible Floor Base Model: 70-BASE